

Process Name/ Title:

**PACKING INSTRUCTION** 

Document No:

WI-ENG-PDE-520

May 5, 2022

Product Code/Name: 7H0336W7020D

WORK INSTRUCTION
e/Name: Customer Code:
7020D NBS

Effective Date: Rev. No.:

0

Page No.:

Page 1 of 1

		7H0336W7020D	NBS		r age 140			
No.	Work Procedure/ Illustration				Records/Remarks/ Quality Pointers			
1)	Put Vinyl Sheet (1520 x 1500)			Qty/ Box Mat'l name	200	10pcs* 20bdls <b>Qty</b>		
				Master box	535*360* 150 mm	1		
	inside the box.			Vinyl Sheet	1520*1500	1		
				Partition Board Plastic	343*510 300*200mm	20		
2		dls of products. (10pcs/bdl) n opposite direction.		DC box. 2. Step nu	Note :  1. For CSW use Oricon box instead of			
3		Put partition board			in	ne bundle has N ner tag inside th inyl bag  SAMPLE INNER  TO NO 1000 1000 1000 1000 1000 1000 1000	TAG	
4	Put 10 bdls of products. (10 pcs/bdl) in opposite direction.					Make sure that the inner tag indicates the correct terminal expiration date.		
(5)	Fold the vinyl sheet.							
6	Clip NBP Identification tag and NBS Tag at the left side of the box							
7	Attach NBS Identification tag at the left side of the box and NBP warehouse tag in the right side of the box.		THUS 7HU3 58W 70 200 13 12 12 12 12 12 12 12 12 12 12 12 12 12		charge in the (warehouse to to its proper le	Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.		
<u></u>					Prepare	Check	Approve	
05/05/2022	0	J. Loterte C. Villanueva A. Arane				C. Villanueva	A. Aranes	
Eff./Rev. Date	Rev. No.	<u> </u>	Details of change	Revise Check A	pprove Est. date	May 5,	2022	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY