					WORK IN	Effectivity Date:			July 10, 2024						
NE			Process Name/Title:		CLA	MP ASSEMBLY P	ROCESS			Validi	ty Date:		n/a		
		7	Model code/Part number:	990B	/ 7N0143-7020	B Customer: TR	J Car Model:	TOYO	TA PRIUS	Docu	ment No.:		WI-ENG-PDE-9	003	
			Purpose:	PROT	ГОТҮРЕ	PRE-LAUNCH	MASSE	PRO		Revis	sion No.:	0	Page No.:	1 of 7	
PARTS:	1	1. Assy parts; Clamp 82711-52090 (W); Protector 730481-5030 (B); Black tape [2 pcs.]; Pink tape									JIG: 1. Clamp Assembly Jig				
NO	Э.	Р	ROCESS NAME		WORK	PROCEDURE/ ILLU	JSTRATION				TOOLS/PPE	LS/PPE QUALITY POINTERS			
1		Clamp Assy	Table Lay-out	Assy par	£5	Tape holder/Pink tape Tape holder/Black tap	Prot	ector 7304 (B)	embly Jig	prince of the control	Afety Instruction Be sure to wear rescribed person of the control	al a		82711-12A80 (W)	
					Revision History	· 					Prepared by	Reviewed by	Approved by	Noted by	
07/10/24		nitial issu	ie.				D.Castillo	C.Villanueva	A. Arañes I	N/A	D. Castillo	South House C.Villanueva	A. Arades	N/A	
Eff. Date	Rev. No			Detai	ils of Change		Revised	Reviewed	Approved N	oted *	Est. Date:	July 10, 2024			



				WORK INS	TRUCTION			Effectivity Date:	1	July 10, 2024	
		Process Name/Title:			P ASSEMBLY PROC	ESS		Validity Date:		n/a	
		Model code/Part number:	990B /	7N0143-7020B	Customer: TRJ		TOYOTA PRIUS	Document No.:		WI-ENG-PDE-9	03
		Purpose:	PROTOT	YPE	PRE-LAUNCH	MASSPF	RO	Revision No.:	0	Page No.:	2 of 7
PARTS:	1. Clamp 82711-52090 (W) 2.Protector 730481-5030 (B)				JIG:	1. Clamp Assembly Jig					
NO.	PROCESS NAME			WORK P	PROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POIN	TERS
2	Clamp	Clamp setting	1. Get the clam location 1 using	p 82711-52090 (W) using both hands.	ing right hand and put to	2. Get the Pput to location	rotector 730481-5030 (Bon 2 and 3 using both hamands.		1. No wron 2. No wron 3. No dama 4. No wvro	g use of parts g use of tape aged clamp ng clamp position at reminders/me check the clamp ssembly to avoid	oote/s:

				K INSTRUCTION			Effectivity Date:		July 10, 2024	'
		Process Name/Title:		LAMP ASSEMBLY PRO			Validity Date:		n/a	
		Model code/Part number:	990B / 7N0143-70	020B Customer: TRJ	Car Model:	TOYOTA PRIUS	Document No.:		WI-ENG-PDE-9	03
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO	Revision No.:	0	Page No.:	3 of 7
PARTS:	1. Assy 2. Blac	parts k tape [2pcs.]		3. Pink tape	JIG:	1. Clamp Assembly Jig				
NO.	F	PROCESS NAME	WC	ORK PROCEDURE/ ILLUSTF	TOOLS/PPE		QUALITY POINTERS			
			Receiver base 1 Connector Setting 6189-0451(W)	2 82711-52090 (W)	Tape 2	asor Pink Only	Protector 730481-5030 (B) SWITCH ASSEMBLY NBC 1		ent reminders/nure no gap between jig.	
3	Clamp Assy	Clamp Assembly	assy parts between the protect to protector 730481-5030 (B) ti into stopper jig then pull down to stopper jig then pull down t	D light for Power On, Clamp e2 was ON. If encountered OP and immediately CALL the eader. WAIT for further instruction	3. Howind hand Conti	eiver Base 1 then lock. S	econd, fix the assy part guide and put the PCB attion 1, make 3 tape using both after taping.	 No wror No dam No wror 	ng use of parts ng use of tape aged clamp ng clamp position vire in protector	5.

				WORK INSTRUCTION		Effectivity Date:		July 10, 2024	ı
		Process Name/Title:		CLAMP ASSEMBLY PROC	ESS	Validity Date:		n/a	
		Model code/Part number:	990B / 7N014	43-7020B Customer: TRJ	Car Model: TOYOTA PRIUS	Document No.:		WI-ENG-PDE-9	003
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 7
PARTS:	1. Assy 2. Blac	/ parts k tape [2pcs.]		3. Pink tape	JIG:	1. Clamp A	1. Clamp Assembly Jig		
NO.	F	PROCESS NAME		WORK PROCEDURE/ ILLUSTRA	TOOLS/PPE	(QUALITY POINTERS		
NO. 3	Clamp	Clamp Assembly (Continuation)	A. Get the pink tape on lo protector. (See bellow illu	lamp 82711-52090 (W) SW button Discation 2, start taping the COT to protector Stration and procedure). Clamp assembly ng. Continue the process if sequence light No clearance between tape an protector	Color Sensor Pink Tape Only Tape Only T. Make half wrap taping untill it cove jig will beep/buzz if the color sensor on clamp location 3 was ON. Taping direction	Protector 730481-5030 (B) SWITCH ASSEMBLY THORSE ASSEMBLY THORS ASSEMBLY THORSE ASSEMBL	1. No wror 2. No wror 3. No dam 4. No wror No loose v	ag use of parts ag use of tape aged clamp ag clamp position wire in protector ant reminders/r sure no gap between	5.

				K INSTRUCTION			Effectivity Date: July 10, 2024			
		Process Name/Title:		LAMP ASSEMBLY PROC			Validity Date:		n/a	
		Model code/Part number:	990B / 7N0143-70	020B Customer: TRJ	Car Model:	TOYOTA PRIUS	Document No.:		WI-ENG-PDE-9	03
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	0	Page No.:	5 of 7
PARTS:	1. Assy 2. Black	parts c tape [2pcs.]		3. Pink tape	JIG:	1. Clamp Assembly Jig				
NO.	F	ROCESS NAME	WC	ORK PROCEDURE/ ILLUSTR	RATION		TOOLS/PPE	QUALITY POINTERS		
3	Clamp	Clamp Assembly (Continuation)	Connector Setting 6189-0451(W) 5. Get the black tape on location wrap taping untill it covers the se	SW button 1 SW button 13, start taping the COT to protect cond side of the protector. (See b) s the SW button after taping GO so No clearanc between tap protector Make pre-tape 2 winds	Color Sensor Tape Or 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	nly 3	Protector 730481-5030 (B) Protector 730481-5030	1. No wror 2. No wror 3. No dam 4. No wror No loose v	ng use of parts ng use of tape aged clamp ng clamp position vire in protector ant reminders/n sure no gap between	ote/s:


				WORK INST		Effectivity Date:	July 10, 2024					
		Process Name/Title:			ASSEMBLY PRO	OCESS		Validity Date:		n/a		
		Model code/Part number:	990B	/ 7N0143-7020B	Customer: TRJ	Car Model:	TOYOTA PRIUS	Document No.:		WI-ENG-PDE-90	3	
		Purpose:	PROTO	TYPE	PRE-LAUNCH	MASSP	PRO	Revision No.:	0	Page No.:	6 of 7	
PARTS:	1. Assy	parts						JIG:	N/A			
NO.	P	ROCESS NAME		WORK P	ROCEDURE/ ILLUS	TRATION		TOOLS/PPE	QUALITY POINTERS			
								MEASURING TAPE 6 7 8 9 (1) 1 2 3 4 5 6 7 8 9 6	1. Pleas measur measur 2. For H Owarim	latsumono, Nakam	erified ting the cono and	
4	Clamp Assy	Measurement		3 25 ±3 (4) 2	(B) (S) ±3	(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	COT Ø7 (B) (I) 159	WHITE	assembl Owarimo	y Hatsumono Naka ono Inspection ng dimension		

			WORK INSTRU	Effectivity Date:	July 10, 2024									
		Process Name/Title:	Process Name/Title: CLAMP ASSEMBLY PROCESS Valid									n/a		
		Model code/Part number:	990B	/ 71	N0143-7020B	Customer:	TRJ	Car Model:	TOYOTA PRIUS	Document No.:		WI-ENG-PDE-9	03	
		Purpose:	PRO	ГОТҮРЕ		PRE-LAUNCH		MASSPR	80	Revision No.:	0	Page No.:	7 of 7	
											ſ			
PARTS:	1. Assy	parts								JIG:	N/A			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7N0143-7020B



1 No Wrong facing of clamp

(2) 3) No Missing Tape (Black tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.