Process Name/ Title: Document No: WI-ENG-PDE-953 **PACKING INSTRUCTION** WORK INSTRUCTION July 04, 2024 Effective Date: Product Code/Name: Customer Code/ Customer: Page 1 of 1 Rev. No.: Page No.: 7N0207 **TRJ** Records/Remarks/ Work Procedure/ Illustration No. **Quality Pointers** 9pcs\* Qty/box 144 Place the sheet inside the 16bdls 1 oricon Mat'l Size Qty. name 386\*55\*2 Oricon 1 box 43 1250\* Vinyl 1 sheet 1250 **Partition** 343\*510 3 board Vinyl 300\*200 16 bag Put the Plastic bag Contact SW assy 9pcs\* 4bdls product (9pcs\*4bundles 2 Step 6 is applicable only to QC FG inspection. Layout partition board inside) (3)Put the product (9pcs\*4bundles) 2nd Layer Layout partition board inside) **(4)** Put the product (9pcs\*4bundles) 3rd Layer Layout partition board



NBC ↔ NT 2 2

Note: If need to attach 4M tag
Put 4M tag at the left side of the box

Prepared by Reviewed by Approved by Noted by

O7/04/24 O Initial Issuance A. Hernandez C. Villanueva A. Arañes n/a A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a A. Arañes n/a A. Hernandez C. Villanueva A. Arañes n/a A. Arañes

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

(5)

6

Put the product (9pcs\*4bundles)

NBC (Philippines)

MASTER COPY