		Process N	lame/ Title: PACKING INSTRUCTION		Document No:			WI-QAD-QAC-322			
	-1	7	WORK INSTRUCTION			ive Date:		April 26, 2025			
			Product Code/Name: Customer Code/ Custom  75S136 TRJ		l l	Rev. No.: <b>1</b>		Page No.:		Page 1 of 1	
No.	Work Procedure/ Illustration							Records/Remarks/ Quality Pointers			
	^							QTY/BOX	400	100pcs. x 4 bundles	
		empty oricon box	×				Material Name	Dimension	Qty.		
1	in the ' after inspection area'					Oricon Box	386*55*243	1			
			1 (28.00)				Vinyl Bag	450*545	4		
2	Put the 100 pcs harness inside plastic vinyl bag in same direction. Put the inner tag inside then fold the plastic bag.		COVID OF 155136-0021 03-25 INF Secretification Tage (R.J. R.)				Partition Board	343*510	3		
3	Put products inside the box and partition board (as shown in the illustration) 100 pcs.*4 bundles with inner tag inside)		Partition								
4	Put NBP identification tag at the top of the packs inside the box. Then put the warehouse identification tag outside the box at lower right side portion.		NOTE: If need to attach 4M tag. Put 4M tag at the left side of the box								
			1					Prepared	Checked A	pproved Noted	
04/26/24			trol number from WI-ENG-PDE-745 to WI-QAD-QAC-322 *Removed Vinyl Sheet size 1500*1500	J. Basañez	D. Dadulla	R. Pascua	O. Merin	-	Qua	MH   (4)	
10/20/23 Eff. Date	0 Rev. No.		Initial Issuance  Details of change	A. Hernandez Prepared	J. Loterte Checked	C. Villanueva Approved	A. Arañes Noted	Basarrez Establish Date:		Pascua O. Merin October 20, 2023	
		•		_			•	****			