

Process Name/ Title: WI-QAD-QAC-007 Document No: **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: May 27, 2021 Customer Code:

Product Code/Name:

7L0031

**TRQSS** 

Rev. No.:

2

Page No.:

Page 1 of 1

No.	Work Procedure/ Illustration					Records/Remarks/		
						Qty/box	Quality Point 50	ers 25pcs*2bdls
1	Put Vinyl Sheet (1520 x 1500) inside carton box.				Mat'l name DC carton	Dim.	Qty.	
					Vinyl sheet Vinyl bag	1520*1500 420*280	2	
2	Put first bdl of products. (25pcs.)					Note: 1. Step number 4 is applicable only in <b>QC FG Inspection</b> .		
3	Put second bdl on upper with opposite direction. (25pcs.)							
4	Fold the vinyl sheet  Then close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box).							
	Note: If need to attach 4M tag Put 4M tag at the left side					Prepared	Checked Appr	oved Noted
05/27/2021 11/15/2018 06/07/2018 Eff./Rev. Date	2 Update sir 1 0 Rev. No.	ep number #4 and put additional note Removal of Silica gel Initial Issue Details of change	C.Dim C.Dim J.Bor Rev	ailig M.Lumbres ete E Mendoza	E Mendoza E Mendoza T.Sugiyama Approve	(J. J.	M. Lumbres P. Men	ndoza A. Arañes

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

**NBC (Philippines) MASTER COPY**