
			WORK INSTRUCTION							Effectivity Date:		June 18, 2024		
K			Process Name/Title:		P ASSEMBLY PRO					ity Date:		n/a		
			Model code/Part number:	310B / 7M0555-7020A	Customer: TRJ	Car Model:	TOYO	TA-RAV	4 Docu	iment No.:		WI-ENG-PDE-	668	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	PRO		Revi	sion No.:	1	Page No.:	1 of 6	
PARTS:		-	parts; Clamp 82711-4821	0 (B);Clamp 82711-52090 (W); Black tape [3pcs.]; Orange tape  WORK PROCEDURE/ ILLUSTRATION						JIG:	·	Clamp Assembly jig  QUALITY POINTERS		
140	<i>J</i> .	•	ROCESS NAME	WORK	ROCEDORE/ IEEOST	KATION				TOOLS/FFL	<del></del>   `	ZUALITI FUIN	IILKS	
		Clamp Assy	' I Jable I av-out	Clamp 82711-48210	TABLE LAY-OU		Clamp 827 (W) /Clan	11-52090 np Tray	p	afety Instruction  Be sure to wear required personal rotective equipmed during operation (gloves, finger cottent)	I 1. No miss	ing parts/tools ss parts/tools CLAMP ILLUSTRATION		
1				Clamp 82/11-48210 (B) /Clamp Tray	Clamp assembly jig			2	Housekeeping Maintain and alwa practice 5's. Personal things the workplace is prohibited. Keep it your locker.	on 82711-5	82711-52090 (W) 82711-12A80 (W)  CLAMP ILLUSTRATION			
				Tape holder/ Black tape	Tape holder/ Orange tape			the	Alert level or any trouble, info e Assembly Assist Supervisor or Line eader for immedia corrective action.	ant e	82711-48210 (B) NG 82711-3F290 (B)			
<u> </u>		I		Revision History		<del>                                     </del>	J	1		Prepared by	Reviewed by	Approved by	Noted by	
										1				
06/18/24	/18/24 1 Improve measurement and visual inspection.					A.Hernandez	C Villanus: :-	A. Arañes	n/a	1				
04/26/23		Initial Issue.  Inclusion of Quality Checkpoints on page no 8: Standardized tube description: VM tube (Supprene). Change Process						C. Villanueva	n/a A. Arañes	Okincm der A.Hernandez	of forth form	A. Arenes	n/a	
Eff. Date	Rev. No			Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	June 02, 2022			




			WORK IN	Effectivity Date:	June 18, 2024					
		Process Name/Title:	CLA	Validity Date:		n/a				
		Model code/Part number:	310B / 7M0555-7020A	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-6	668
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	20	Revision No.:		Page No.:	2 of 6
PARTS:	1. Clan 2. Clan	np 82711-48210 (B) np 82711-52090 (W) [2pcs.	3. Black tape ] 4. Orange tap				JIG:	1. Clamp a	ssembly jig	
NO.	F	PROCESS NAME	WORK	( PROCEDURE/ ILLUST	RATION		TOOLS/PPE		QUALITY POIN	ITERS
2	Clamp Assy	Clamp Setting	1. Get 1pc. of clamp 82711-48210  2. Get 2pcs. of clamp 82711-5209  3. Initially attach Orange tape on 3 using both hands.	0 (B)  82711-  0 (B) then attach to location 1  90 (W) then attach to location	4 52090 (W) and 2	ocation 1, 2 and		1. No wron 2. No wron 3. No dams 4. No wron  STAN  O  Important 1. Please of assemb	g use of parts g use of tape aged clamp g clamp position  DARD TAPING F  ne side tape under the side tape under the clamp by to avoid wrong  CLAMP ILLUSTRATION  CLAMP ILLUSTRATION  NG	OR CLAMP  er clamp  /s: first before start use of clamp.

			WORK INS	Effectivity Date:	June 18, 2024						
		Process Name/Title:		MP ASSEMBLY PRO	DCESS		Validity Date:	n/a			
	H	Model code/Part number:	310B / 7M0555-7020A	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-6	68	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	1	Page No.:	3 of 6	
PARTS:	1. Assy	parts					JIG:	1. Clamp a	ssembly jig		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUST	TRATION		TOOLS/PPE	QUALITY POINTERS			
3	Clamp Assy	Clamp Assembly	CONNECTOR SETTING  Checker 1  Connector Setting  Co	Checker 2  See above picture for contractive for continuity checking. Last, set the hin the stopper then press  I, Clamp On, Wire1 & Hality, STOP and Beleader. WAIT for occess.  The start taping using then cut the tape.	rrect setting of I king. Second, se terminal end tog	harness). First, set the continue if the sequence of the seque	terminal to terminal to	Make s and termin      No dama	ged clamp g usage of parts		

WORK INSTRUCTION Effectivity Date								June 18, 2024				
		Process Name/Title:	CLAN	MP ASSEMBLY PRO	OCESS		Validity Date:	n/a WI-ENG-PDE-668				
		Model code/Part number:	310B / 7M0555-7020A	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:					
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	1	Page No.:	4 of 6		
PARTS:	1. Assy	<i>ı</i> parts					JIG:	1. Clamp a	assembly jig			
NO.	ı	PROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS							
3	Clamp		Connector setting  Checker 1  Checker 1  Connector setting  4. Hold the tape on clamp location 2 the both hands. Make 3 windings of tape Press the SW button after taping. Corlight in location 3 was on.  6. Hold the tape on clamp location 4 the windings of tape then cut the tape. (In detects Orange tape on the first wing Go sound will be heard.	e then cut the tape. ntinue if sequence  hen start taping using both Note: Color sensor light	Color Sense ORANGE TA only  82711-5  2  5. Hold the tape hands. Make 3 will beep/buzz if	on clamp location 3 there windings of tape then cutaping. Continue if sequences	USE ORANGE TAPE  In start taping using both the tape. Press the ence light in location 4  In start taping using both the tape. Press the ence light in location 4	Importa  1. Make s and term	ant reminders/sure no gap between in als	/note/s:		



		WORK INSTRUCTION						June 18, 2024		
	Process Name/Title:	CLAN	IP ASSEMBLY PRO	Validity Date: n/a						
	Model code/Part number:	310B / 7M0555-7020A	Customer: TRJ	Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-	668		
	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 6		
						ı				
PARTS:	1. Assy parts				JIG:	n/a				
		A MOUNT MODEOTION								
	✓1\ VISUAL INSPECTION									
CLAN	MP ASSEMBLY	7M0555-7020A								



- **No Missing Clamp**
- 2 No Wrong Color of Tape (Orange tape only)
- (3) No Misalign Clamp