

Process Name/ Title:
PACKING INSTRUCTION

Document No:

WI-QAD-QAC-255

April 24, 2024

WORK INSTRUCTION
Product Code/Name: Custor
A7446 TF

Customer Code: TRQSS

Effective Date: Rev. No.:

0

Page No.:

Page 1 of 1

		A7446	IRQSS						
No.	Work Procedure/ Illustration					Records/Remarks/ Quality Pointers			
1)	(1520					Qty/box Mat'l name DC carton	50 Dim. 1131*781	25pcs*2bdls Qty.	
		Put Vinyl Sheet (1520 x 1500) side carton box.				Vinyl sheet	1520*1500	1	
							Vinyl bag	420*280	2
2		Put first bdl of roducts. (25pcs.)			Plastic vinyl bag CSW assy	of		oer 4 is applicable	only in QC FG
3	Put sec op	ond bdl on upper with posite direction. (25pcs.)							
4	Close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box . Note: If need to Put 4M to				attach 4M tag	PINES			
							Prepare	Check	Approve
 	ļ						Shin	(Nu.)	Ju, /
04/24/2024	0		Initial Issue	A. De Chavez	D. Dadulla	R. Pascua	A. De Chavez	D. Dadulla	R. Pasoua
Eff./Rev. Date	Rev. No.		Details of change	Revise	Check	Approve	Est. date:	April 24,	2024

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY