			WORK INSTRUCTION									October 21, 2024			
			Process Name/Title:	Process Name/Title: TAPING ASSEMBLY PROCESS Validity Date:									·		
			Model code/Part number:	240B / 7M0514-7021		Car Model:	LEX	(US-ES	Docu	ment No.:		WI-ENG-PDE-11	25A		
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSF			Revis	sion No.:	1	Page No.:	1 of 4		
PARTS:		Assy parts; Black Corrugated tube (with slit) Ø5 L=670±6mm; Black tape								JIG: 1. COT adopter					
N	ο.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE				QUALITY POINTERS			
					Ве	1. 1		Document reference/s: 1. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance							
1		P1	Table lay-out	Black Corrugated tube (with slit) Ø5 L=670±6mm COT adopter Assy parts						Housekeeping Maintain and alwa practice 5's. Personal things on orkplace is prohibit keep it in your locke	2. Refeassements the led. 1. No mis	2. Refer to WI-ENG-PDE-1124 for Cassembly process 1. No missing parts/tools 2. No excess parts/tools			
					Black tape with tape holder	210((1)1111)	13 W 13 3 4 6 1 1		th Su _l	Alert level or any trouble, info ne Assembly Assista pervisor or Line Lea r immediate correct action.	ant ader				
				The first transfer	diam.			2.0							
		l		Revision Histo	ory		ı	ı		Prepared by	Reviewed by	Approved by	Noted by		
10/21/24	1	Change from Pre-launch to Masspro. D.Castillo C. Villanueva A. A.							n/a	0	1/4:11	Alax			
10/17/24	0	Initial issue. Separate wire insertion to connector and connector lock to Offline assembly process.					C. Villanueva	A. Arañes	n/a	D. Castillo	C. Villanueva				
Eff. Date	Rev. No	Details of Change				Revised	Reviewed	Approved I	Noted	Est. Date:	October 17, 2024				

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



			WORK INS	Effectivity Date:	October 21, 2024				
		Process Name/Title:	TAPIN	NG ASSEMBLY PROC	Validity Date:	n/a			
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ	Car Model: LEXUS-ES	Document No.:		WI-ENG-PDE-112	25A
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 4
PARTS:	1. Assy 2. Black	parts Corrugated tube (with slit) ø5	i L=670±6mm	670±6mm 3. Black tape		JIG:	n/a	n/a	
NO.	F	PROCESS NAME	WORK I	PROCEDURE/ ILLUSTR	TOOLS/PPE	QUALITY POINTERS			
2	P1	Spot taping 1. Fix the hotmelted wire and terminal pointed tip using both hands. 2. Hold the wires using left hand, get the Black tape using right hand then make 2 windings of tape using both hands. Note: Position of spot taping must be right beside Gray tape.					1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape		
3		Wire insertion to Black Corrugated tube (with slit) ø5 L=670±6mm	1. Hold the COT adaptor using left hand. Combined the 2 assy parts ar put inside the COT adaptor using righand	R L l	2. Hold the COT adaptor with wires using left hand, get the Black Corrugated tube (w/slit) ø5 L=670±6mm using right hand and insert to COT adaptor. Pull the adaptor and push the COT (same timing) using both hands. Make sure all wires are inserted.			g use of parts left in between the C	COT with slit

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

			WORK INS	Effectivity Date:	October 21, 2024						
		Process Name/Title:	TAPIN	Validity Date:	n/a						
		Model code/Part number:	240B / 7M0514-7021B	Customer: TRJ Car Mod		Car Model:	LEXUS-ES	Document No.:	WI-ENG-PDE-1125A		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	1	MASSPRO)	Revision No.:	1	Page No.:	3 of 4
PARTS:	1. Assy 2. Black							JIG:	n/a		
NO.	PROCESS NAME			PROCEDURE	/ ILLUSTR	ATION		TOOLS/PPE	QUALITY POINTERS		
NO. 4 P1		Taping 1 Black corrugated tube (with slit) to wire near terminal and PCB	1 2 3 4 5	0±3mm	tape using	2. Measure f up to termina 120±3mm ar 116±3mm th taping proce hands.	hand, get the Black pre-taping at the using both hands. From end of COT all pointed tip and COT to PCB en continue the ss using both Ifter taping, check measurement, hinal alignment and and condition.	n/a	1. Please measurismeasure Docum 1. Please taping p 1. No peel- 2. No flip of 3. No loose 4. No wron- 5. No wron- 6. No missi	off tape to tape to tape to tape to tape to tape to tape g use of tape g dimension ng tape	rified ng the S: ASY-001 for

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

			WORK INS	Effectivity Date:	October 21, 2024						
		Process Name/Title:	TAPIN	ASSEMBLY PROC	Validity Date:	n/a					
		Model code/Part number:	240B / 7M0514-7021B		Customer: TRJ	Car Model:	LEXUS-ES	Document No.:	WI-ENG-PDE-1125A		25A
		Purpose:	☐ PROTOTYPE		PRE-LAUNCH	■ MASSPRO		Revision No.:	1	Page No.:	4 of 4
PARTS:	1 Assv	parts						.llG·	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P1

7M0514-7021B



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY