
_			WORK INSTRUCTION							tivity Date:		October 18, 2024		
			Process Name/Title: OFFLINE ASSEMBLY PROCESS							ity Date:		n/a		
			Model code/Part number:	310D / 7N0199-7020B	Customer: TRQSS	Car Model:	TOYO	TA-RAV4	Docu	ment No.:		WI-ENG-PDE-1	060	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO		Revis	sion No.:	1	Page No.:	1 of 7	
PARTS:		L=135±3mm (no slit)		SSf 0.3 Black wires L=768±3mm; AVSSf 0.3 Violet wires L=768±3mm; Black Corrugated tube ø5						JIG:	2. Termina	Insertion jig with switch cover Terminal cover jig		
NO	0.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POIN	ITERS	
1		Offline Table lay-out		Connector 6098- 3802 (W)/ Connector tray AVSSf 0.3 Black wires L=768±3mm Locking jig Black Corrugated tube ø5 L=135±3mm (no slit) Locking jig Terminal cover jig					p (glo	Safety Instructio Be sure to wear required persona rotective equipme during operation oves, finger cots, Housekeeping Maintain and alw practice 5's. Personal things the workplace is orohibited. Keep it your locker. Alert level or any trouble, info e Assembly Assist Supervisor or Line eader for immedia corrective action.	2. No exce 2. No exce 2. No exce 1. Refer Strip len 6000 6008- orm tant e ate	1. No missing parts/tools 2. No excess parts/tools Document references: 1. Refer to WI-PRO-CNC-017 for Wire Strip lenght tolerance. CONNECTOR ILLUSTRATION GOOD NG GOOD NG GOOD OGOS 6098-3802 (W) GOOS-5668 (W)		
		ı		Revision History		<u> </u>	1			Prepared by	Reviewed by	Approved by	Noted by	
										1				
10/18/24	1	Change	purpose from Pre-launch to Massp	oro.		M. Ariola	C.Villanueva	A. Arañes	n/a	Muely	Month Willow			
09/24/24	0	Initial iss	ue.			M. Ariola	C.Villanueva	A. Arañes	n/a	M. Ariola	C.Villanueva	A. Arañes	n/a	
Eff. Date	Rev. No			Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	September 24, 2024			
CONFIDE	CONFIDENTIAL: Any misuse or misappropriation, including													


unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)


MASTER COP


MASTER COPY





			WORK IN	Effectivity Date:	October 18, 2024					
		Process Name/Title:	Validity Date:	n/a						
		Model code/Part number:	310D / 7N0199-7020B Customer: TRQSS Car Model: TOYOTA-RAV4				Document No.:	WI-ENG-PDE-1060		
		Purpose:	PROTOTYPE	PRE-LAUNC	H MASSP	PRO	Revision No.:	1	Page No.:	4 of 7
PARTS:	1. Assy Parts						JIG:	1. Locking	jig	
NO.	I	PROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS					
4	Offline	Connector lock	1. Load the connector into the jig hold both side of the connector, tip first. Right thumb-Lower Left thumb-middle 3. Press the lower parts of connector right hand while left hand holding the right thumb-middle Entry thumb-middle Left thumb-middle 5. Lift then press the connector in the middle using left and right hand.	using niddle.	2. Press the lower part of insert into the locking jig Right thumb- Left thumb- 4. Press the upper part of chand while left hand holding the lock based on the sequence on the sequence of the lock based on	of connector to fully described by the middle connector using right g the middle.	LOCKING JIG	2. No unlo	00D	onnector lote/s: y caused c. 017 for the






			WORK INSTRUCTION						Effectivity Date:	October 18, 2024		
			Process Name/Title:	OFFLI	Validity Date:	n/a						
			Model code/Part number:	310D / 7N0199-7020B	Customer:	TRQSS	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-1	060
			Purpose:	PROTOTYPE	PRE-LAUNCH	l	MASSPR	0	Revision No.:	1	Page No.:	7 of 7
	PARTS:	1. Assy	1. Assy parts							n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

OFFLINE INSERTION

7N0199-7020B





- (1) No Unlocked/half-locked connector
- 2 No Wrong insert
- (3) No Deformed terminal

- 4 No Terminal Backing
- 5 No Missing COT

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.