_	WORK INSTRUCTION								Effec	ctivity Date:		June 11, 2024			
			Process Name/Title:		TAPIN	IG ASSEMBLY PROC	ESS			Valid	lity Date:		n/a		
			Model code/Part number:	310B /	7M0521-7021	Customer: TRJ	Car Model:	TOYO	TA-RAV4	Docu	ıment No.:		WI-ENG-PDE-4	16B	
			Purpose:	PROTOTY	PE.	PRE-LAUNCH	MASSP	RO		Revi	sion No.:	2	Page No.:	1 of 7	
PARTS:		1. Assy	parts; Black VM tube (Sur	nprene) Ø11 L=120	±3mm; Black tape						JIG:	n/a	n/a		
N	0.	Р	ROCESS NAME		WORK	PROCEDURE/ ILLUSTR/	ATION				TOOLS/PPE		QUALITY POINTERS		
	1	P2		Table Lay-out			Black VM tube (Sunprene) Ø11 L=120±3mm			1. 2	afety Instruction Be sure to wear or escribed person rotective equipmed during operation gloves, finger cotect.)  Housekeeping Maintain and alword practice 5's. Personal things the workplace is or or biblied. Keep it your locker.	al a	No missing parts/tools     No excess parts/tools		
Bia						Black tape/Tape holder			Assy part	the	Alert level or any trouble, inforce Assembly Assis Supervisor or Line eader for immedia corrective action	ant e te			
		•			Revision History					•	Prepared by	Reviewed by	Approved by	Noted by	
00/44/61		la aluai	of Car model "TOYOTA-RAV 4"	l and Management of			D.Castillo	C.Villanueva	A. Arañes	N/A	-				
06/11/24	1	Standard Reminde	ized tube description: VM tube ( rs, notes and references on pag	Sunprene);Inclusion of	Quality Checkpoints on pa	age no. 6; Improve Quality pointers:	M. Ariola	J. Loterte	C. Villanueva A		Jestino	Month than			
02/23/22		Initial Iss	ue.				K. Doria	J. Loterte	Villanueva A	Arañes	D. Castillo	C.Villanueva	A. Aranes	N/A	
Eff. Date	Rev. No	Details of Change				Revised	Reviewed	Approved	Noted	Est. Date:	February 23, 2022				

NBC (Philippines)
MASTER COPY

			WORK INS	Effectivity Date:	June 11, 2024						
		Process Name/Title:	TAPIN	Validity Date:	n/a						
		Model code/Part number:	310B / 7M0521-7021	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-41	16B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	2	Page No.:	2 of 7	
PARTS:	1. Assy 2. Blac						JIG:	n/a			
NO.	F	PROCESS NAME	WORK I	PROCEDURE/ ILLUST	RATION		TOOLS/PPE	(	QUALITY POIN	TERS	
2	P2	Taping 2 Black corrugated tube to wire near hotmelt	Start of Taping  131±3mm  131±3mm  131±3mm  20±3mm  131±3mm	460±4mm between Co	Measure from election to en continue the total	and of the corrugated hotmelt 131±3mm taping process.		1. Please measurin measurer  1. No flip-c 2. No peel- 3. No loose 4. No miss 5. No wron 6. No wron	out tape -off tape e tape ing tape ing dimension ing use of tape ent reference/s:	rified g the	



			WORK IN		Effectivity Date:	June 11, 2024					
		Process Name/Title:	TAPII		Validity Date:	n/a					
		Model code/Part number:	310B / 7M0521-7021	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-416	SB	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	2	Page No.:	3 of 7	
PARTS:	1. Assy parts 2. Black VM tube (Sunprene) Ø11 L=120±3mm 3. Black tape						JIG:	n/a			
NO.	Р	ROCESS NAME	WORK	PROCEDURE/ ILLUS	TRATION		TOOLS/PPE	(	QUALITY POINT	ERS	
3		Wire insertion to assy parts		L=120	t the VM tube (Su 0±3mm using righ V wire using left r	nt hand then insert the	n/a	1. No wron	g use of parts		
4	P2	Taping 3 Black VM tube (Sunprene) to Black Corrugated tube	20±3mm  20±3mm	ping  2. Hold the VM		) using left ht hand.	6789(0123456789)	1. Please measuring measurem  1. No flip-o 2. No peel- 3. No loose 4. No missi 5. No wron 6. No wron	out tape -off tape -e tape ing tape g dimension g use of tape -ent reference/s:	fied the	



WORK INSTRUCTION Effectivity Date: June 11, 2024												
		Process Name/Title:	TAPIN	Validity Date:		n/a						
		Model code/Part number:	310B / 7M0521-7021 Customer: TRJ Car Model: TOYOTA-RAV4		Document No.:	WI-ENG-PDE-416B						
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	2	Page No.:	4 of 7		
PARTS:	1. Assy	by parts ck tape					JIG:	n/a				
NO.	I	PROCESS NAME	WORK	PROCEDURE/ ILLUST	RATION		TOOLS/PPE	/PPE QUALITY POINTERS				
5	P2	Y-Taping	THE REAL PROPERTY.	Corrugated tu left side , widt	g at the middle oubes, then wind the must be 20±3	the tape to 3mm.  1/3 shifting until it ide of corrugated tube	n/a	1. Use Yi visualizati should be 1. No flip-c 2. No peel 3. No loos 4. No miss 5. No wron 6. No wron	I-off tape e tape sing tape ng dimension ng use of tape  nent reference/s to WI-PRO-ASY-0	easy but actual		



	WORK INSTRUCTION Effectivity Date: June 11, 2024											
		Process Name/Title:			OCESS				n/a	<u>·</u>		
						TOYOTA-RAV4	-		WI-ENG-PDE-41	16B		
Process Name/Title:  Model code/Part number:  310B / 7M0521-7021  Customer: TRJ  Car Model: TOYOTA-RAV4  Document No.:  WI-ENG-PDE-4  Purpose:  PARTS:  1. Assy parts 2. Black tape	5 of 7											
PARTS:	2. Blac	k tape										
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS				
5	P2		Tape shifting 9mm below	4. W	Vind the tape 1/2 s	shifting going to other e then cut the tape.	MEASURING TAPE	1. Use YE visualization should be 1. No flip-ce 2. No peel- 3. No loose 4. No miss 5. No wron 6. No wron  Docum.  1. Refer	ELLOW TAPE for on of shifting lines BLACK TAPE  but tape off tape e tape ing time tape ing dimension g use of tape  to WI-PRO-ASY-0	easy but actual		



			WORK INS	TRUCTION	Effectivity Date:	June 11, 2024				
		Process Name/Title:	TAPIN	G ASSEMBLY PRO	CESS		Validity Date:		n/a	
		Model code/Part number:	310D/ 7N0191-7020A	Customer: TRJ	Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-410	6B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	1	Page No.:	6 of 7
PARTS:	1. Assy	parts	^				JIG:	n/a		
NO.	F	ROCESS NAME	✓2 WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
4	P1	Measurement	② 131±3 ③ 20±3 VM Tube (Sunprene) (B) Ø11 NOTE: A - Taping (B)	<u>COT 97</u>		(a) 0 <sup>+5</sup> (core)	MEASURING TAPE  6 7 8 9 10 1 2 3 4 \$ 6 7 8 9 10 12 3 4 \$ 6 7 8 9 1	Importa 1. Pleas measure 2. For H Owarim  Docum 1. Refer assembly Owarimo	nnt reminders and se use calibrated/v ing tape when get ement. latsumono, Nakan	note/s: rerified ting the nono and



			Effectivity Date:	June 11, 2024					
		Process Name/Title:	TAPIN	Validity Date:	n/a				
		Model code/Part number:	310B / 7M0521-7021	Customer: TRJ	Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-4	16B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	7 of 7
PARTS: 1. Assy parts JIG:							n/a		
				SIIAL INSPECTION/OU/					

## VISUAL INSPECTION/ QUALITY CHECKPOINTS

## 7M0521-7021 **P2** 2 No MISSING TAPE 3 No MISSING VM tube (Sunprene)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY