

PACKING INSTRUCTION

Document No:

WI-QAD-QAC-213

WORK INSTRUCTION

Customer Code: Effective Date:

November 23, 2024

Product Code/Name: **7L0119**

TRQSS

Rev. No.:

3

Page No.:

Page 1 of 1

		720119	IRQSS						
No.	Work Procedure/ Illustration					Records/Remarks/ Quality Pointers			
	Put Vinyl				Qty/box	54 🔏	27pcs *2bdls		
1	Sheet (1250 x 1250)				Mat'l name	Dim.	Qty.		
	inside carton box.				DC carton	1131*781	1		
					Vinyl sheet	1250*1250	1		
						420*280	2		
2	Put first bundle of products. (27pcs/bundle)					mber 5 is ap _l FG Inspect i			
3	Put second bundle on the other side with opposite direction (27pcs/bundle)								
4	Fold the vinyl sheet.								
(5)	Close the flaps and pu ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box).		Note: If need to	o attach 4M tag					

						Prepare	Check	Approved
11/23/2024	3	Change quantity per bundle from 25 pcs to 27 pcs Change total packing quantity from 50 pcs to 54 pcs	A. De Chavez	D.Dadulla	R.Pascua/ O.Merin			
06/04/2024	2	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua			
09/23/2022	1	Change document control number from WI-ENG-PDE-246 to WI-QAD-QAC-213	M. Garcia	R. Alcantara	A. Arañes	16:	Aua	4./ (6.
02/25/2021	0	Initial Issuance Note: Under WI-ENG-PDE-246	J.Loterte	C. Villanueva	A. Arañes	A. De Chavez	D.Dadulla	R.Pascua/Ø.Merin
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date:	February 25, 2021	1

Put 4M tag at the left side

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY