			WORK INSTRUCTION						Effectivity Date:		March 15, 2025			
			Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:		n/a			
			Model code/Part number:	311D/ 7L0156-7022	Customer: TRQSS	Car Model:	TOYOTA-R	AV 4	Document No.:		WI-ENG-PDE-1	201		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO		Revision No.:	1	Page No.:	1 of 5		
PARTS:		Assy parts Black SV tube (vinyl) ø5 t=0.5 L=95±3mm Pink Tape					JIG:	n/a						
NO			PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	(QUALITY POIN	TERS		
TABLE LAY-OUT Black SV tube (vinyl) e5 t=0.5 L= 95±3mm Housekeeping 1. Maintain and always practice 5s. 2. Personal things on the workplace is prohibited. Keep tin your locker. Tape holder / Pink tape Tape holder / Pink tape														
I				INEVISION FIISION			<u> </u>		Prepared by	Checked by	Reviewed by	Approved by		
03/15/25	5 1 Change purpose from Pre-launch to Masspro. M. Ariola J. Loterte C. Villanueva A. Arañes							1/-/	SHOW					
02/12/25 0 Initial issue. M. Ariola n/a C. Villanueva A. Arañes M. Ariola J. Lot							J. Loverte	.C.Villanueva	A. Arañes					
Eff. Date Rev. No Details of Change Revised Checked Reviewed Approved Est. Date: February 12, 2025														




			WORK INS	Effectivity Date:	March 15, 2025					
		Process Name/Title:	Validity Date: n/a							
		Model code/Part number:	311D/ 7L0156-7022	Customer: TRQSS	Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-12	201
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	1	Page No.:	2 of 5
PARTS:	1. Assy parts 2. Black SV tube (Vlnyl) ø5 L=95±		.3mm				JIG:	n/a		
NO.	F	ROCESS NAME	ME WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS		
2	P1	Wire Insertion to Black Black SV tube (VInyl) ø5 L=95±3mm	Hold the assy part using left hand hand then insert.	d and get Black SV tube (Vlnyl) ø5 L=95±3	mm using right	n/a	1. No wron 2. No defor	g usage of parts med terminal	

NBC (Philippines)
MASTER COPY

			WORK IN	Effectivity Date:	March 15, 2025					
		Process Name/Title:	TAPIN	Validity Date:	n/a					
		Model code/Part number:	311D/ 7L0156-7022	Customer: T	RQSS Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-1	201
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO	Revision No.:	1	Page No.:	3 of 5
PARTS:	1. Assy 2. Pink						JIG:	n/a		
NO.	F	PROCESS NAME	WORK	TOOLS/PPE	(QUALITY POINTERS				
3	P1	Taping 1 Corrugated tube to wire near Connector	Start taping Start taping O-5mm 25±3mm 3. After taping, check the measurement	R R	1. Hold the Black S\ left hand and measurable (Vinyl) up to co	t hand then start ls.		5. No wron 6. No miss Importar 1. Please measuri measure Docume 1. Prefer Sub Ass wire and	off tape e tape g dimension g use of tape ing tape out reminders/Note e use calibrated/ ing tape when ge ement. out reference/s: to WI-PRO-ASY- y Taping Procedu COT to VT) Wire alignment to	verified tting the 001B Rev.2 ure (VT to






NBC (Philippines)

MASTER COPY

	C	WORK INSTRUCTION E						Effectivity Date:	March 15, 2025		
		Process Name/Title:	TAPIN	Validity Date:		n/a					
		Model code/Part number:	311D/ 7L0156-7022	Customer:	TRQSS	Car Model:	TOYOTA-RAV 4	Document No.:		WI-ENG-PDE-1	201
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPR	0	Revision No.:	1	Page No.:	5 of 5
PARTS:	n/a							JIG:	n/a		
VISUAL INSPECTION/QUALITY CHECKPOINTS											

TAPING-P1

7L0156-7022



1 No Missing Tape/Wrong color of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY