
			WORK INSTRUCTION							Effectivity Date:		October 14, 2024		
			Process Name/Title:		G ASSEMB	LY PROCESS			Valid	dity Date:		n/a		
			Model code/Part number:	220D / 7L0134-7020B	Customer:	TRQSS Car Mode	: LE	XUS-LM	Docu	ument No.:		WI-ENG-PDE-10	099C	
			Purpose:	PROTOTYPE	PRE-LAUNCH	I MAS	SPRO		Revi	sion No.:	1	Page No.:	1 of 7	
PARTS		_	y parts; Black tape							JIG:	n/a			
N.	0.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						_	TOOLS/PPE		QUALITY POIN	ITERS		
				TABLE LAY-OUT					l p	Be sure to wear prescribed person rotective equipme during operation (gloves, finger cot etc.)	al ent			
1		P3	Table Lay-out	Assy part					2	Housekeeping Maintain and alwa practice 5's. 2. Personal things the workplace is prohibited. Keep it your locker.	ays 1. No mis 2. No exc	No missing parts in assy parts     No excess tape/tape holder     No wrong position of tape holder		
				152 ± 2mm 710134-7020 11 2 3 4 5 6 7 6 9 10 1 2 3 4 5	160 ±3mm 71.0134-70 (01.2.3.4.6,6.7.8.6		n n		th	Alert level or any trouble, info e Assembly Assist Supervisor or Lin eader for immedia corrective action.	tant e ate			
	Revision History					1	Prepared by	Reviewed by	Approved by	Noted by				
10/14/24	1	Change from Pre-launch to Masspro.  D.Castillo  D.Castillo  A. Arañes						/ A. Arañes	n/a	0	1//	Alax		
10/09/24		Initial issue. Seprate clamp assembly. Transfer process from P1 and P2.  D.Castillo  C.Villanuev a  A. Arañes							n/a	D.Castillo	C. Villanueva	A. Arañes	n/a	
Eff. Date	Ate Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: October 08, 2024													






WORK INSTRUCTION Effectivity Date: October 14, 2024											
		Process Name/Title:		G ASSEMBLY PROCESS		Validity Date:	Ocit	n/a			
			220D / 7L0134-7020B	Customer: TRQSS Car Model:	LEXUS-LM		\A/I FA	NG-PDE-1099C			
		Model code/Part number:				Document No.:					
		Purpose:	PROTOTYPE	PRE-LAUNCH MASSPRO		Revision No.:	1 Pag	ge No.: 3 of 7			
PARTS:	1. Assy 2. Black	parts c tape				JIG:	n/a				
NO.	F	ROCESS NAME	WORK F	PROCEDURE/ ILLUSTRATION		TOOLS/PPE	OOLS/PPE QUALITY POINTERS				
3	P3	Taping 5 Black SV tube (Vinyl) to wire near connector	1. Hold vinyl tube using left hand, measure from SV tube (Vinyl) up to end of connector 25±3mm.  25±3mm  25±3mm	a. After taping check the measurement, wire alignme taping condition.	Black tape using and, hold the SV vinyl) using left hen fold the SV vinyl) and start using right hand.	6 7 8 9 1 1 2 3 4 5 6 7 8 9 were 10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1. Please use call measuring tape with measurement.  1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong use of 6. No wrong dimental pocument references.	when getting the  e  f  g  g  g  g  g  g  g  g  g  g  g  g			



			October 14, 2024						
		Process Name/Title:	TAPING A	SSEMBLY PROCES	Validity Date:	n/a			
		Model code/Part number:	220D / 7L0134-7020B	Customer: TRQSS Car	r Model: LEXUS-LM	Document No.:		WI-ENG-PDE-109	99C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 7
PARTS:	1. Assy 2. Black	parts k tape [1pc]		JIG:	n/a				
NO.	F	PROCESS NAME	WORK PRO	TOOLS/PPE	TOOLS/PPE QUALIT				
4	P3	Y-Taping	CONNECTOR FACING  Upper tube tape attachment R  taping direction  Tape shifting 1/2  Tape shifting 1/3		ated tube. onnector facing  2. Start taping at the middl the tape on the upper tube windings. Note: Do not exert excess winding of tape.	e of combined tubes, attach. Then make pre-tape 2	1. No loose 2. No flip-c 3. No peel- 4. No wron 5. No wron 6. No expo 7. No gap 8. Follow ti  Docum 1. Refe taping  Importa 1. Use y visualiz actual s 2. Pleas	e tape out tape -off tape ng use of tape ng use of tape ng dimension-out ta ssed wire between tubes he connector facing ment reference/s: er to WI-PRO-ASY- procedure (specia ant reminders/Not yellow tape for eat action of tape shift should be BLACK se use calibrated/ ring tape when get	ope  001C for al).  e/e/s: sy sing, but TAPE. verified

		WORK INSTRUCTION Effectivity Date:							October 14, 2024			
		Process Name/Title:	TAPING A	ASSEMBLY PROC	ESS		Validity Date:		n/a			
		Model code/Part number:	220D / 7L0134-7020B	Customer: TRQSS	Car Model:	EXUS-LM	Document No.:		WI-ENG-PDE-10	)99C		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	5 of 7		
PARTS:		/ parts k tape					JIG:	n/a				
NO.		PROCESS NAME	WORK PRO		TOOLS/PPE	QUALITY POINTERS						
4	P3	Y-Taping (Continuation)	Tape shifting 1/2  Tape shifting 1/2  Tape shifting 1/2  9. Winding the tape 1/2 shifting going to the side until it reach the other side of tube  11. conduct proper pressing of end tape using left hand (top part)	7. Winding the tape 1/2 shifting going to the left side.  10. Make  12. conduct proper p tape using left hand (		tape c  tape c  tape c  13. conduct pro	8. Make 2 windings, width must be 23±2mm.  eutting  en cut the tape.  poper pressing of end hand (bottom part)	5. No wror 6. No expo 7. No gap  Docum 1. Refe taping Importa 1. Use y visualiza actual s 2. Pleas measuri measure  25	out tape -off tape of tape og use of tape og dimension-out to sed wire between tubes  ment reference/s: r to WI-PRO-ASY procedure (spec ant reminders/No cellow tape for ea ation of tape shift hould be BLACK be use calibrated/ ing tape when ge ement.	te/s: sy ting, but TAPE. verified tting the		





Ī			WORK INSTRUCTION							Effectivity Date: October 14, 2024							
		G	Process Name/Title:	ess Name/Title: TAPING ASSEMBLY PROCESS Va							n/a						
								Model code/Part number:	220D / 7L0134-7020B	Customer:	TRQSS	Car Model:	LEXUS-LM	Document No.:		WI-ENG-PDE-10	99C
ıL			Purpose:	PROTOTYPE	PRE-LAUNCH	I	MASSPRO		Revision No.:	1	Page No.:	7 of 7					
[	PARTS:	1 Assv	parts						JIG:	n/a							
-		1. Assy parts					0.0.	.,, a									

## **VISUAL INSPECTION/ QUALITY CHECKPOINTS**

## TAPING - P3

## 7L0134-7020B



123

No Missing Tape
No wrong use of tape (Black)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.