
					TRUCTION				Effectivity Date:		October 01, 2024		
			Process Name/Title:	TAPIN	G ASSEMBI	LY PROC	ESS	-	Validity Date:		n/a		
	-1		Model code/Part number:	241B / 7L0049-7023A	Customer:	<b>TRQSS</b>	Car Model:	<b>LEXUS ES</b>	Document No.:		WI-ENG-PDE-10	67A	
			Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	0	Revision No.:	1	Page No.:	1 of 12	
PARTS:		1. Connector 6188-0066 GR; 6189-1161 (B); AVSSf 0.3 wires Y-OR L=380±2mm; MRSW CP (TVSS (Sunprene) Ø5 L=106±3mm); Black Corrugated tube (no slit) Ø7 L=49±3mm; Corrugated tube (no slit) Ø7 L=312±3mm; Black tape  PROCESS NAME  WORK PROCEDURE/ ILLUS							JIG:	Locking j     Terminal	Insertion jig with switch cover     Locking jig     Terminal cover jig		
1		P1	Table Lay-out	Insertion jig with switch cover  Insertion jig B  Insertion jig C	Y	T (no slit)	97 L=3		Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. Refer and Strip 2. Refer Taping v 1. No missin 2. No exces	ant reference/s: to WI-PRO-CNC- to Length Tolerar to WI-PRO-KIT-O with Vinyl Tube  ang parts/tools as parts/tools	ice	
				Revision History					Prepared by	Reviewed by	Approved by	Noted by	
10/01/24	0	Change f	rom Pre-launch to Masspro.				A.	C. A. Arañes C. G. A. Arañes	n/a n/a O'RIM CM Ju A.Hernandez	S. Villanueva	A. MERROS	n/a	
Eff. Date	Rev. No			Details of Change			Revised R	Reviewed Approved	Noted Est. Date: Se	ptember 24, 2024			




			WORK IN:		Effectivity Date:	October 01, 2024				
		Process Name/Title:		NG ASSEMBLY PRO			Validity Date:		n/a	
		Model code/Part number:	241B / 7L0049-7023A	Customer: TRQSS	Car Model:	<b>LEXUS ES</b>	Document No.:		WI-ENG-PDE-1067A	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	)	Revision No.:	1	Page No.: 2 of 12	
PARTS:	1. Con	nector 6188-0066 (GR)					JIG:	1. Insertion	n jig with switch cover	
NO.	l	PROCESS NAME	WORK		TOOLS/PPE	(	QUALITY POINTERS			
2	P1	Connector setting to Insertion jig 6188-0066 (GR)	Orange wire  Visual reference	Yellow wire	-mark Lock	r orientation  sertion jig rientation	N/A	I-m a	CONNECTOR ORIENTATION ILLUSTRATION  1 hole is open align  2 holes are open t align	
			Press R  1. Press the lock using left hand.	Press  2. Get the connector 6188 insert to insertion jig. Rele Note: Follow the connect	ease the lock afte	er insertion.		2. No wron 3. No wron	e provided jig per model ng orientation of connector ng use of connector naged connector	


WORK INSTRUCTION Effectivity Date: October 01, 2024											
		Process Name/Title:	TAPIN	G ASSEMBL	Y PROCESS		Validity Date:		n/a		
		Model code/Part number:	241B / 7L0049-7023A	Customer:	TRQSS Car Model:	LEXUS ES	Document No.:	WI-ENG-PDE-1067A			
		Purpose:	□РГОТОТУРЕ	PRE-LAUNCH	MASSPR	)	Revision No.:	1	Page No.:	3 of 12	
PARTS:	1. Insertior	1. Insertion jig with switch cover									
NO.	F	PROCESS NAME	TOOLS/PPE	(	QUALITY POIN	ΓERS					
3	P1	Wire Insertion to connector 6188-0066 (GR)	1. Hold the insertion jig using left hand Get the Yellow wire and insert to connector using right hand.  2 Orange wi  3. Get the Orange wire and insert to connector using right hand.		Press  2. Press the button us for Orange wire will be press  4. After insertion, push that thumb and then hold the pull out the connector from hand.	ne lock using left wires and gently	N/A	Import Import I. Plea Inserte Conduinserti Do not Docum I. Refe Pull-P 2. Refe	g insertion one insertion rm terminal ng wire facing  ant reminders/No use hold the wire re e sure wires are p ed. ct Pull-Push-Pull-	near terminal. properly Push after -029 for -017 for	









	WORK INSTRUCTION Effectivity Date: October 01, 2024												
		Process Name/Title:	TAPING AS	SSEMBLY PROCESS		Validity Date:		n/a					
		Model code/Part number:	<b>241B / 7L0049-7023A</b> c	Customer: TRQSS Car Model: L	EXUS ES	Document No.:		WI-ENG-PDE-10	67A				
		Purpose:	PROTOTYPE P	RE-LAUNCH MASSPRO		Revision No.:	1	Page No.:	6 of 12				
PARTS:	1. Blac 2. Ass					JIG:	1. Insertion	Jig					
NO.	NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINT												
6	P1	Wire Insertion to Connector 6189-1161 (B)	1. Hold the insertion jig using left hand. Get the Yellow wire and insert to connector using right hand.  1. Wellow wire and insert to connector using right hand.  1. Wellow wire and insert to connector using right hand.	2. Press the button using right Orange wire will be open.  4. After insertion, push the lock usi and then hold the wires and gently connector from jig using right hand	ng left thumb pull out the	N/A	4. No deforms. 5. No wron Important 1. Please terminal 2. Make properly Conduct after instance Do not et al. Reference 1. Reference 5. No wron wron wron wron wron wron wron wro	g insertion one insertion one insertion on terminal g wire facing one reminders/Note e hold the wire ne sure wires are inserted. the pull-Push-Pull-F	ear Push				







			WORK INS	TRUCTION				Effectivity Date:		0 1 1 01 00	24
		Process Name/Title:		G ASSEMB	I V DDAC	EGG		Validity Date:		October 01, 202 n/a	24
						1	I EVIIC EC	· · · · · · · · · · · · · · · · · · ·			
	5	Model code/Part number:	241B / 7L0049-7023A	Customer:		Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-10	
		Purpose:	PROTOTYPE	PRE-LAUNCH	1	MASSPRO		Revision No.:	1	Page No.:	10 of 12
PARTS:	1. Assy	parts						JIG:	1. Insertion	ı jig	
NO.	F	PROCESS NAME	WORK P	ROCEDURE	/ ILLUSTRA	ATION		TOOLS/PPE	(	QUALITY POIN	TERS
12	P1	Wire insertion to connector 6188-0066 (GR) (Assy parts)	1. Hold the insertion jig using left hand.  1. Hold the insert to connector stusing right hand.  2 Green  1. Hold the insert to connector stusing right hand.	get 4. Afte	2. Press the Black/White	e wire will be on	ght hand, slot for bened.	N/A	4. No deforms 5. No wrong 5. No wrong 5. No wrong 6. N	ng insertion one insertion rm terminal ng wire facing  ont reminders/Note e hold the wire ne l. sure wires are or inserted. t Pull-Push-Pull-F	ear Push

from jig using right hand.

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

slot 2 using right hand.

			WORK	INSTRUCTION			Effectivity Date:		October 01, 20	24		
		Process Name/Title:		PING ASSEMBLY PRO	OCESS		Validity Date:	n/a				
	H	Model code/Part number:	241B / 7L0049-7023/		S Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-10	067A		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	)	Revision No.:	1	Page No.:	11 of 12		
PARTS:	1. Assy	parts					JIG:	1. Locking	Jig			
NO.	F	PROCESS NAME	WOI	RK PROCEDURE/ ILLUS	FRATION		TOOLS/PPE	QUALITY POIN	TERS			
13	P1	Connector lock	Before	1. Put the connector then press 2x. Touclocked.  2. Touclocked.  2. Touclocked.  3. Put the connector then press 2x. Touclocked.  4. Touclocked.	After pressing	DD	LOCKING JIG	1. Use the	rtant reminders/NUAL LOCKING SE DAMAGED CO provided locking j	ig per model		

Process Name/Title:	WORK INST	RUCTION S ASSEMBLY PROCESS	Effectivity Date: Validity Date:	24					
Model code/Part number:	241B / 7L0049-7023A	Customer: TRQSS Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-10	67A		
Purpose:	PROTOTYPE	PRE-LAUNCH MASS	PRO	Revision No.:	1	Page No.:	12 of 12		
PARTS: 1. Assy parts	VISI	IAL INSPECTION/ QUALITY CH	ECK DOINTS	JIG:	n/a				
TAPING - P1	Visc		.0049-7	023A					
17111110 72			20043 7	OL S/ (					
No Unlocked /Half-locked /Connector  V OR  2 3 No Wrong Insert									
1	4	5	(5) (6) N	No Missing No Missing Sunprene No Termina No Deforme	Black tube I Back	king ou	ıt		