	WORK INSTRUCTION Effectivity Date: September 20, 2023											
			Process Name/Title:		NG ASSEMBLY PRO	ree		fractivity Date:		n/a	023	
		7	Model code/Part number:	420B/440B / A7448C	<u> </u>	Car Model: TOYOTA-LAND		Oocument No.:		WI-ENG-PDE-7		
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	F	Revision No.:	1	Page No.:	1 of 8	
PARTS: 1. Assy parts 2. Black tape			k tape	<b>A</b>				JIG:	1. Insertion 2. Locking j	ig		
N	0.	F	PROCESS NAME	<u>∕1</u> \ WORK	PROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	(	QUALITY POIN	TERS	
	1	P2	Table lay-out	Assy parts Insertion jig	Locking jig	e holder/ Black tape		Safety Instruction Be sure to wear prescribed persona protective equipme during operation (gloves, finger cots etc.)  Housekeeping 1. Maintain and alwa practice 5's. 2. Personal things of the workplace is prohibited. Keep it if your locker.  Alert level For any trouble, infor the Assembly Assists Supervisor or Line Leader for immedia corrective action.	1. No miss 2. No exce	ing parts/tools ss parts/tools		
		1		Revision History			I	Prepared by	Reviewed by	Approved by	Noted by	
09/20/2023				o. Additional Table lay-out; Update Work procedu	ure/Illustration on page no. 3 and 4.	M. Ariola J. Loterte C. Villa	anueva A. Araf	0	Shot	Month ) Hours	- (1)	
09/11/2023	_	Initial Iss	ue.			M. Ariola J. Loterte C. Villa	anueva A. Arañ		J. Loterte	C. Villanueva	A. Arañes	
Eff. Date	Rev. No			Details of Change		Revised Reviewed Appro	roved Note	d Est. Date:	September 11, 2023	3	~	

			WORK INST			Effectivity Date:		September 20, 202	23	
		Process Name/Title:		S ASSEMBLY PROC		Validity Date:	<b></b>	n/a		
		Model code/Part number:	420B/440B / A7448C	Customer: TRQSS	Car Model: TOYOTA-LAND CRUISER	Document No.:	<u> </u>	WI-ENG-PDE-735	iВ	
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 8	
PARTS:	1. Assy 2. Black	tape					1. Insertion jig			
NO.	F	ROCESS NAME	MORK PF	ROCEDURE/ ILLUSTRA	TION	TOOLS/PPE	QUALITY POINTERS			
2	P2	Taping 1 Black Corrugated tube to Black SV tube (Vinyl)	99 ± 3mm  L  Start taping  R  99 ± 3mm  R  10 1 2 3 4 5 6 7 8 9 5 1 1	2. Hold the assy parts using get the black tape using both taping process using both	ng left hand, then ght hand then start	6789 123456789	1. Please measurin measure  1. No flip-or 2. No peel- 3. No loose 4. No missi 5. No wrong	out tape -of tape e tape	erified	



	WORK INSTRUCTION Effectivity Date: September 20, 2023											
		Process Name/Title:	TAPING ASSEMBLY PROCESS	Validity Date:	n/a							
		Model code/Part number:	420B/440B / A7448C Customer: TRQSS Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-73	35B					
		Purpose:	☐ PROTOTYPE ☐ PRE-LAUNCH ■ MASSPRO	Revision No.:	1	Page No.:	3 of 8					
PARTS:	1. Assy	parts		JIG:	1. Insertion jig							
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION	TOOLS/PPE	(	QUALITY POIN	TERS					
3	P2	Connector setting to insertion jig 6189-0093 (W)	INSERTION JIG  Visual reference  Button  Wire guide  INSERTION JIG ORIENTATION  1. Push the lower wire guide upward using right thumb. Slot for Green wire will be opened.  1. Push the wire guide upward using right thumb. Slot for Green wire will be opened.  1. Push the wire guide upward using right thumb.  1. Push the wire guide upward using right thand. Slot for Green wire will be opened.	n/a	<ol><li>No wror</li><li>No wror</li></ol>	provided jig per m ng orientation of co ng use of connecto naged connector	nnector					

NIDA			WORK II	Effectivity Date:	September 20, 2023				
		Process Name/Title:	TAP	ING ASSEMBL	LY PROCESS	Validity Date:		n/a	
		Model code/Part number:	420B/440B / A7448C	Customer:	TRQSS Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-73	35B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO MASSPRO	Revision No.:	1	Page No.:	4 of 8
PARTS:	1. Assy	parts				JIG:	1. Insertion jig		
NO.	F	PROCESS NAME	1 WOR	TOOLS/PPE		QUALITY POIN	TERS		
4		Wire insertion to Black SV tube (Vinyl) [Assy parts]	R L		1. Hold the assy parts using left hand then insert the G-B/W wires with assy parts using right hand.	n/a		ng usage of parts irmed terminal	
5	P2	Wire insertion to connector 6189-0093 (W)	1 Hold the Green wire then insert terminal slot 1 using right hand.  R  3. Hold the B/W wire then insert to terminal slot 2 using right hand.		2. Press the button using right thumb. The slot for B/W wire will be opened.  4. After insertion, push the lock using left thumb then hold the wires and gently pull out the connector from jig using right hand.	n/a	2. No loos 3. No wrot 4. One by 5. No defo 6. No wro  Importan 1. Please 2. Make sinserted. Conduct insertion Do not e.	Pull-Push-Pull-Pu	/s: ar terminal. operly ush after e/s:

			WORK	Effectivity Date: September 20,			)23		
		Process Name/Title:	TA	PING ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	420B/440B / A7448C	Customer: TRQS	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-73	5B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 8
PARTS:	1. Assy į	parts		JIG:	1. Locking jig				
NO.	Р	ROCESS NAME	WOF	RK PROCEDURE/ ILLUST	RATION	TOOLS/PPE	QUALITY POINTERS		
6		Connector lock	1. Put the connector into locking jie and then press 2x. Check the conlock.	Unlock Condition Half Lock  GOOD  Woode lock  Good lock  Full Lock  Good lock  Full Lock  Good lock  Full Lock  Full Lock  Full Lock  The state of t	Before pressing After pressing	LOCKING JIG	2. No unlo	vided locking jig pe ck/half-locked conr ocument referenc se refer to GL-PRC Push procedure.	nector re/s:
7	P2	Taping 2 Black SV tube (Vinyl) to wire near connector		t. Hold the SV tube Vinyl) using left hand then get the plack tape using light hand then start aping on the 3/4 hart of the SV tube Vinyl) using both hands.	rom end of Black SV tube (Vinyl) tor 76±3mm  76±3mm  76±3mm  After taping, check the leasurement and taping condition		6. No wror	-of tape e tape	and verified

			WOF		Effectivity Date: September 20, 2023					
		Process Name/Title:		TAPING ASSEMBLY PRO	CESS	Validity Date:		n/a		
		Model code/Part number:	420B/440B / A7448	C Customer: TRQS	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	35B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 8	
PARTS:	1. Assy 2. Black					JIG:	n/a			
NO.	F	PROCESS NAME	W	ORK PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE		QUALITY POIN	TERS	
8	P2	Y-Taping	L 2. Sta Corru	3. Confirm Tap of tape up to el	tape shifting 1/3 below taping direction  R  wind the  e width measurement from end and of Combined tubes then ping process using both hands.	MEASURING TAPE	6. No wron  Importal 1. Use Y visualizs should I 2. Pleas	-of tape e tape sing tape ng use of tape ng dimension  out reminders/Note ELLOW TAPE for ation of shifting li be BLACK TAPE, be use calibrated/ung tape when get	easy nes, but actual verified	

**MASTER COPY** 

WORK INSTRUCTION Effectivity Date: September 20, 2023 Process Name/Title: TAPING ASSEMBLY PROCESS Validity Date: n/a												
		Process Name/Title:	Validity Date:		n/a							
	H	Model code/Part number:	420B/440B / A	<b>A7448C</b>	Customer: TRQSS	Car Model: TOYOTA-LAND	CRUISER	Document No.:		WI-ENG-PDE-73	5B	
		Purpose:	☐ PROTOTYPE	P	RE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	7 of 8	
PARTS:	1. Assy 2. Blac							JIG:	n/a			
NO.	F	PROCESS NAME		WORK PROC	EDURE/ ILLUSTR/	ATION		TOOLS/PPE	(	QUALITY POIN	ΓERS	
8	P2	Y-Taping (Continuation)	taping direction taping direction tape w  tape shifting 1/3 be  taping direction tape w  taping direction tape w  taping direction tape w  tape w  taping direction tape w  tape w  tape w  taping direction tape w	tape shifting 1/2 below  Tape width  taping direction  of tape then wind the ag to other side of	1/2 shifting go 56 ± :	dings of tape then wind ing to other side.	Tape		6. No wron  Importar  1. Use Yilly visualiza should b	-of tape e tape e tape ing tape ng use of tape ng dimension  out reminders/Note ELLOW TAPE for ation of shifting libe e BLACK TAPE. e use calibrated/v ng tape when get	easy nes, but actual erified	

		WORK INSTRUCTION						September 20, 2023			
	Process Name/Title:	TAPI	Validity Date:	n/a							
	Model code/Part number:	420B/440B / A7448C	Customer:	<b>TRQSS</b>	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	35B		
	Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	8 of 8		
							1				
PARTS: n/a	a a					JIG:	n/a				

## QUALITY CHECKPOINTS



**GOOD** 

- 1) No WRONG INSERT No UNLOCKED/HALFLOCKED **NO TERMINAL BACKING OUT**
- (2) (3) No MISSING TAPE
- 4 No DEFORMED TERMINAL/PCB

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.