			WORK INST						ivity Date:			January 23, 202	24
		Process Name/Title:	CLAMF	P ASSEMBLY PROCE	ESS			Validity Date:		n/a			
		Model code/Part number:	700B / 7N0038-7020A	Customer: TRJ	Car Model:	TOYOTA LA	ND-CRUISER	Docun	ment No.:			WI-ENG-PDE-8	12
		Purpose:	□PROTOTYPE	PRE-LAUNCH	MASSP	RO		Revisi	on No.:		0	Page No.:	1 of 6
PARTS:	1. Assy Parts 4. Clamp 82711-3A540 (W) 2. Clamp 82711-52090 (W) 5. Black tape [4pcs] 3. Clamp 82711-48070 (GR) [3pcs] 6. Violet tape [1pc]								JIG:	1.	Clamp Assembly jig		
NO.		PROCESS NAME WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE		QUALITY POINTERS						
1	n/a	Table Lay-out	Clamp 82711-48070 (GR)/ Clamp Tray Assy Parts	TABLE LAY-OUT Clamp 82711-52090 (W. Clamp Tray) Black tape/Tape holder			Tray	for the s	afety Instruction Be sure to wear equired personal tective equipmer during operation loves, finger cots, etc.) Housekeeping Maintain and alwa practice 5's. Personal things o the workplace is obhibited. Keep it in your locker. Alert level any trouble, infor Assembly Assista upervisor or Line ader for immediat corrective action.	nt , , , , , , , , , , , , ,	No missir	ng parts/tools ss parts/tools	
<u> </u>			Revision History		T T				Prepared by	Revie	wed by	Approved by	Noted by
01/23/24 0	Initial is	sue.			A.Hernandez	C.Villanueva A	A. Arañes	n/a	Okumendez A.Hernandez	C.Villa		A. Grades	n/a
Eff. Date Rev. No	0		Details of Change		Revised	Reviewed A	Approved N	loted	Est. Date:	January 2	3, 2024		



WORK INSTRUCTION Effectivity Date: January 23, 2024											
		Process Name/Title:	CLAM	Validity Date:	n/a						
		Model code/Part number:	700B / 7N0038-7020A	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	112		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6		
PARTS:	2.Clam	p 82711-48070 (GR) [3pcs] p 82711-52090 (W) p 82711-3A540 (W)		4. Violet Tape 5. Black tape [4 po			Clamp Assembly jig				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POINTERS				
2	n/a	Clamp setting	1. Get 3pcs. of clamp 82711-48070 (vland and set to clamp location 1, 4 and hands. 2. Get 2pcs. of clamp 82711-52090 (vland set to clamp location 2 using both and set to clamp location 3 using both	v) using right hand hands.	4. Initially attach Violet tape to clamp to hands. 5. Initially attach Black tape to clamp to using both hands.	82711-48070 (GR)	2. No wron 3. No dam: 4. No wron Impor 1. Please before wrong CC	g use of parts g use of tape aged clamp g clamp position retant reminders/N se check the Clar start of assembly use of clamp. One side tape under CLAMPILLUSTRATION NG 8271	np first v to avoid		

NBC (Philippines)

MASTER COPY

			WORK INS	Effectivity Date:	January 23, 2024					
		Process Name/Title: Model code/Part number:	CLAMP ASSEMBLY PROCESS 700B / 7N0038-7020A Customer: TRJ Car Model: TOYOTA LAND-CRUISE			-	Validity Date:	•		
		Purpose:	PROTOTYPE	Customer: IRJ	MASSPRO		Revision No.:	0	Page No.:	3 of 6
		pooc.							- ago man	
PARTS:	1. Assy	v parts					JIG:	1. Clamp As	ssembly jig	
NO.	PROCESS NAME		WORK	PROCEDURE/ ILLUS	STRATION		TOOLS/PPE	(QUALITY POIN	ITERS
3	n/a	Clamp Assembly	1. Put the assy into jig. (See above picture connector 6098-3802 (W) to Recein jig. Last, set G-B-V wires together w. 2. Check if all LED Light for POWER (abnormallity, STOP) and immediately C further instruction and continue the promotion 3. Hold the tape on clamp location 1, m tape using both hands. Press the Switce location 2. 4. Hold the tape on clamp location 2, m tape using both hands. Press the Switce location 3. 5. Hold the tape on clamp location 3, m tape using both hands. Press the Switce location 4.	ver base 1, continue to s rithin stopper then press to the press to th	ting). First, set let the harness by toggle clamp. If encountered leader, WAIT for then cut the ntinue to clamp then cut the ntinue to clamp then cut the ntinue to clamp then cut the	ings of tape then s. Press the Switc nue to clamp loca lold the tape on cla lings of tape then	amp location 5, make 3 cut the tape using both ch button after taping.	1. Pleabefore wrong Import 1. Make stopped 1. No loost 2. No dam 3. No miss	e side tape under	mp first y to avoid :/Note/s: eween

NBC (Philippines)

MASTER COPY

	WORK INSTRUCTION Effectivity Date: January 23, 2024										
					2000	Effectivity Date:					
		Process Name/Title:		IP ASSEMBLY P		Validity Date:	n/a				
		Model code/Part number:	700B / 7N0038-7020A	Customer: TR.	J Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	312		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 6		
							,				
PARTS:	1. Assy parts					JIG:	n/a				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE					TOOLS/PPE	QUALITY POINTERS				
4	n/a	Measurement	145±5mm 61±3mm 0~5mm	116±3mm 75±3mm		228±3mm SURING TAPE	1. Pleas measuri measuri 2. For H. Docum 1. Referassemb	g dimension nt reminders/Not e use calibrated/ ing tape when ge ement. atsumono and O ent reference/s: r to WI-PRO-ASY- bly Hatsomono, N arimono Inspect	verified tting the warimono. -056 for Sub lakamono,		



				NSTRUCTION			Effectivity Date:		January 23, 202	24
		Process Name/Title:					Validity Date:		n/a	
		Model code/Part number:	700B / 7N0038-7020A		Car Model: TOYOTA LANI	D-CRUISER	Document No.:		WI-ENG-PDE-81	2
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	I	Revision No.:	0	Page No.:	5 of 6
PARTS:	Assy parts Master sample						JIG:	n/a		
NO.	F	PROCESS NAME	WOR	K PROCEDURE/ ILLUST	RATION		TOOLS/PPE	G	QUALITY POINT	ERS
5	n/a	Visual/By Two's Inspection		2. Check the connector lock condition, insertion. 4. Check the presence of condition and color of tap	Cond overl	neck the Tapin duct slightly be look of missi	ACTUAL PRODUCT ng condition. ending to avoid		Checking during ins	


NBC (Philippines)

MASTER COPY

			Effectivity Date: January 23, 2024			24			
		Process Name/Title:	Validity Date:	n/a					
		Model code/Part number:	700B / 7N0038-7020A	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	12
		Purpose:	PROTOTYPE	□PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 6
PARTS:	n/a					JIG:	n/a		
QUALITY CHECKPOINTS									

CLAMP

7N0038-7020A





NO GOOD

(3) (4) No Wrong use of tape

color of tape

No missing Clamp/No wrong

- 1 No Unlock/
 Halflocked Connector
 (on connector)
- No Wrong Insert (on connector)
- Checking of Clamp alignment/

No Deformed terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

6