

			WORK INSTRUCTION							Effec	tivity Date:	e: January 26, 2024				
			Process Name/Title: TAPING ASSEMBLY PROCESS							Valid	ity Date:		n/a			
		H	Model code/Part number:	ES1 /	7M0515-7021 Cust	omer: TRJ	Car Model	SL	JBARU	Docu	ment No.:		WI-ENG-PDE-7	70C		
			Purpose:	PROTOTYPE	☐ PRE-	LAUNCH	MASS	SPRO		Revis	sion No.:	0	Page No.:	1 of 5		
PARTS:		1. All pa	arts: Assy parts; Black VM	tube (Sunprene) ø9 L=73±3mm; Black tape						JIG:	n/a	n/a				
NO	Э.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POINTERS				
1		Table lay-out Black VM tube (Sunprene) e9 L=73±3mm Black tape/Tape holder Revision History							global for the state of the sta	afety Instructi Be sure to wear prescribed persor rotective equipm during operation poves, finger cots, Housekeeping Maintain and alw practice 5's. Personal things the workplace is prohibited. Keep it your locker. Alert level or any trouble, infer assembly Assis Supervisor or Lir eader for immedit corrective action	on in	No missing parts/tools No excess parts/tools				
	Revision History							•	Prepared by	Reviewed by	Approved by	Noted by				
											_					
							1	-			Jestivo	Sout withour	(Q)			
01/26/2024	0 1	Initial issu	ue				D.Castillo	C. Villanueva	A. Arañes	n/a	D. Castillo	C. Villanueva	A Arapes	n/a		
Eff. Date	Rev. No			Details of Ch	ange		Revised	Reviewed	Approved	Noted	Est. Date:	January 26, 2024	7	.,, u		











				WORK INST	Effectivity Date:	January 26, 2024					
		Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:	n/a		
		Model code/Part number:	ES1 /	7M0515-7021	Customer: TRJ	Car Model:	SUBARU	Document No.:		WI-ENG-PDE-77	70C
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPRO)	Revision No.:	0	Page No.:	4 of 5
PARTS:		tape [1pc]						JIG:	n/a		
NO.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	QUALITY POINTERS		
4	P3	Y-taping	tapes	tape width	a. Winding other side of 25mm. 1. Fix the other side of 2 corrugate of 25mm. 2. Start tap Corrugate of 2 corrugate of 25mm.	the tape 1/3 shifting for corrugated tubes appeared	of combined ding the tape going to just be Tape width. ing until it reach the e, width must be	MEASURING TAPE	1. Use YI visualiza actual st 2. Please measuris measure Docume 1. Refer process 1. No flip-02. No peel 3. No loos 4. No miss 5. No wror	ent references: to WI-PRO-ASY-0t Dut tape -off tape e tape	easy nes, but <u>TAPE.</u> erified ing the

NBC (Philippines)

MASTER COPY

Purpose:	mber: ES1 /	7M0515-7021 Cus	TION SSEMBLY PROC ustomer: TRJ	Car Model:	SUBARU	Effectivity Date: Validity Date: Document No.: Revision No.:	0	January 26, 202 n/a WI-ENG-PDE-77 Page No.:					
PARTS: n/a			QUALITY CHEC	CKPOINTS		JIG:	n/a						
WOALITT OHLONG ONTO													
P3 7M0515-7021													
13 / 1410313-1021													
	W												
	1)					1		3					
A CONTRACTOR OF THE PARTY OF TH	THE RESERVE OF THE PERSON NAMED IN COLUMN 1												
	and the second s		Se with the first team of the	N P OF STATE OF STREET, STATE OF STATE AND STREET, STATE OF STATE	ar Ange (samus) and unsured to the total and a second to the term of the second to the second to the second to	AND							
						Market St.							

1 No MISSING TAPE 2 NO MISSING VM TUBE 3 NO DEFORMED TERMINAL AND HOTMELTED

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY