			WORK INSTRUCTION								ctivity Date:		September 13, 2024		
			Process Name/Title:	TAPIN	G ASSEMB	LY PROCE	ESS			Valid	lity Date:		n/a		
			Model code/Part number:	922B / 7L0124-7022A	Customer:	TRQSS	Car Model:	LEX	XUS NX	Docu	ument No.:		WI-ENG-PDE-10	044B	
			Purpose:	PROTOTYPE	PRE-LAUNCH	l	MASS	PRO		Revi	sion No.:	1	Page No.:	1 of 6	
PARTS:	I. Assy parts; Black tape; Black Corrugated tube(with slit) Ø5 L=317±3mm NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION								JIG: 1. COT Adaptor TOOLS/PPE QUALITY POIN			ITERS			
										10013/111		QUALITTOINTERO			
					TABLE LA	Y-OUT Black Cor tube(wir Ø5 L=31	th slit)		0	bi k	afety Instruction Be sure to wear orescribed person rotective equipment during operation (gloves, finger contects)	al ent			
	1	P2	Table Lay-out		rt	1. Mainta prac 2. Perso the w prohibite			Housekeeping Maintain and alw. practice 5's. Personal things the workplace is prohibited. Keep it your locker.	1. No mi 2. No ex	No missing parts in assy parts No excess tape/tape holder				
					COT	111111111111111111111111111111111111111		Тар	k Tape / e Holder	the L	Alert level or any trouble, info e Assembly Assist Supervisor or Line eader for immedia corrective action	ant e ite			
				Revision History							Prepared by	Reviewed by	Approved by	Noted by	
				·							. Toparoa by		7 pp. 0100 Sy	110.00 29	
09/13/24	1	Change fr	rom Pre-launch to Masspro.				D.Castillo	C.Villanuev a	A. Arañes	n/a		, ,			
09/10/24	a						A. Arañes	n/a	D.Castillo	C.Villanueva	out) for A.				
Eff. Date	Rev. No	Details of Change Revised Reviewed Approved Noted Est. Date: Septmeber 10, 202									24				



			WORK INS	Effectivity Date:	September 13, 2024					
		Process Name/Title:	TAPING	Validity Date:		n/a				
		Model code/Part number:	922B / 7L0124-7022A	Customer: TRQSS	Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-10	44B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	2 of 6
		·								
PARTS:	parts tape	JIG:	n/a							
NO.	P	ROCESS NAME	WORK P	ROCEDURE/ ILLUSTRA	TION		TOOLS/PPE	(QUALITY POIN	TERS
2	P2	Taping 2 Black corrugated tube to Black SV tube (Vinyl)	tube and (Vinyl) u hands. N	ted tube and	R	2. Get the Black tape and start taping process using both hands.	Measuring tape 6 7 8 9 10 1 2 3 4 5 6 7 8 9 6	1. Please utape when 2. Must be tube. Docume 1. Please taping pro 1. No flip-or 2. No peel-d 3. No loose 4. No missi	ut tape off tape tape ng tape g use of tape	ied measuring Irement. COT and Vinyl



			WORK INS	Effectivity Date:	September 13, 2024							
		Process Name/Title:	TAPIN	Validity Date:		n/a						
		Model code/Part number:	922B / 7L0124-7022A	Customer: TRQSS	Car Model: LEXUS N	X Document No.:		WI-ENG-PDE-10	44B			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 6			
1. Assy parts												
PARTS:	2. Black	tape				JIG:	n/a	n∕a				
NO.	F	ROCESS NAME	WORK F	TOOLS/PPE	QUALITY POINTERS							
3	P2	Taping 3 Black SV tube (Vinyl) to wire near connector	1. Hold vinyl tube using left hand, measure from SV tube (Vinyl) up to end of connector 25±3mm. 25 ± 3mm 25 ± 3mm	measureme taping condi	2. Get Black tape us right hand, hold the Stube (Vinyl) (ø5 L=64±3mm) using let hand then fold the Stube (Vinyl) and start taping using right hand the stube (Vinyl) and start taping using right hand the stube (Vinyl) and start taping using right hand the start taping using right hand the start taping using right hand taping using right hand the start taping using right hand the start taping using right hand taping using right hand the start taping using right hand taping using	t	1. Please umeasurem Docume 1. Please taping pro 1. No flip-o 2. No peel- 3. No loose 4. No missi 5. No wron	ent references: refer to WI-PRO-A cedure. ut tape off tape tape	ied g the			

NBC (Philippines)
MASTER COPY

			WORK IN	ISTRUCTION			Effectivity Date:		September 13, 2	024
		Process Name/Title:	TAPI		Validity Date:	n/a				
		Model code/Part number:	922B / 7L0124-7022A	Customer: T	RQSS Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-104	44B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	5 of 6
PARTS: 1. As 2. Bla		sy parts ck tape					JIG:	JIG: n/a		
NO.	F	PROCESS NAME	WORK	TOOLS/PPE QUALITY POINTERS			TERS			
4		Wire Insertion to assy parts	1. Hold the Black VM tube (Su insert the assy parts using right	nprene) Ø5 L=96±3m	m using left hand then co	ntinue to	n/a	No wrong usage of parts No wrong insertion		
5	P2	Spot taping		R 2. Bl www. M. be	Fix the hotmelted wire are using both hands. Hold the wires using letack tape using right hare indings of tape using boote: Position of spot tapeside Black tape. Check the wire alignment and the condition.	ft hand, get the ad then make 2 oth hands.	n/a	1. No flip-c 2. No peel- 3. No loose 4. No wron	off tape	



	_		WORK INST	RUCTION			Effectivity Date:		September 13, 2	2024
	AL	Process Name/Title:	TAPING	Validity Date:		n/a				
		Model code/Part number:	922B / 7L0124-7022A	Customer: TRQSS	Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-104	44B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	5 of 6
PARTS:	1. Blacl	Corrugated tube(with slit)	Ø5 L=317±3mm	JIG: 1. COT Adaptor						
NO.	F	ROCESS NAME	TOOLS/PPE	QUALITY POINTERS						
6	P2	Wire insertion to Black Corrugated tube (w/slit) ø5 L=317±3mm	1. Hold the COT adaptor using inside the COT adaptor using	2. Hold the Cusing left han Corrugated the L=317±3mm insert to COT adaptor and p	OT adaptor with d, get the Black ube (w/slit) ø5 using right han adaptor. Pull th bush the COT (s	n wires k d and ne same	COT Adaptor	1. No wron 2. No wires	ng use of parts s left in between th	e COT with slit


NBC (Philippines)
MASTER COPY

		WORK INSTRUCTION E							Effectivity Date:	September 13, 2024			
		Process Name/Title:	ocess Name/Title: TAPING ASSEMBLY PROCESS							n/a			
		Model code/Part number:	922B /	7L0124-7022A	Customer:	TRQSS	Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-10	44B	
		Purpose:	PROTOT	YPE	PRE-LAUNCH	1	MASSPRO		Revision No.:	1	Page No.:	6 of 6	
	1												
PARTS:	S: 1. Assy parts						JIG:	n/a					

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P2

7L0124-7022A



1 2 No Missing Tape

3 No Missing COT (w/ slit)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY