


	WORK INSTRUCTION								Effectivity Date: May 15,			;	
			Process Name/Title:		Validity Date:		n/a						
		H	Model code/Part number:	311D / 7L0152-7024	Customer: TRQS	S Car Model:	TOYOTA	RAV 4	Document No.:		WI-ENG-PDE-1	258	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSF	PRO		Revision No.:	1	Page No.:	1 of 7	
PARTS:	S: 1. Assy parts; clamp 82711-48210 (B) [2 pcs.]; Clamp 82711-3A640 (B); Clamp 82711-33650 (B); Bla						.]		JIG:	1. Clamp A	1. Clamp Assembly jig		
NC).	Р	ROCESS NAME	WORK	RATION			TOOLS/PPE		QUALITY POINTERS			
1	Clamp 82711- 48210 (B) Table Lay-out Clamp 82711- 3A640 (B) Assy parts Black tape/ holder				Clamp 827 33650 (E	ssembly Jig	NBC OF THE STATE O	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistan Supervisor or Line Leader for immediate corrective action.	1. Refer Offline a 2. Refer and Strij 1. No miss 2. No exce	Important reminders/Note/s: 1. Refer to WI-ENG-PDE-675 for Offline assembly process 2. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance 1. No missing parts/tools 2. No excess parts/tools			
Revision History							Prepared by	Checked by	Reviewed by	Approved by			
										<u> </u>			
05/15/25	1 (Change d	ocuments purpose from pre-launc	h to mass pro		A 11		### A A	rañes Okumonduz	(Show	Month offarm	AND	
04/28/25		Initial issu				A.Hernandez A.Hernandez			rañes A.Hernandez	J.Loverte	C. Villanueva	A. Arañes	
Eff. Date	Rev. No			Details of Change		Revised				ril 28, 2025	J. Villariaova	71.71141100	




	WORK INSTRUCTION Effectivity Date:								May 15, 2025			
		Process Name/Title:	uy 10;		n/a	,						
		Model code/Part number:	CLAN 311D / 7L0152-7024		WI-ENG-PDE-1258							
		Purpose:	□РКОТОТУРЕ	Customer: TRC	Car Model: TO	DYOTA RAV 4	Revision No.:	1	Page No.:	2 of 7		
PARTS:	1. Assy parts 2. Clamp 82711-48210 (B) [2 pcs.] 3. Clamp 82711-3A640 (B)			JIG:	1. Clamp	1. Clamp Assembly jig						
NO.		PROCESS NAME	WORK	PROCEDURE/ ILLU	STRATION		TOOLS/PPE		QUALITY POIN	ITERS		
2	Clamp Assy	Clamp Setting	82711-48210 (B) 1. Get 1pc. of clamp 82711- 2. Get 1pc. of clamp 82711- 3. Get 1pc. of clamp 82711- 4. Initially attach Black tape	3A640 (B) using right ha	and and set to clamp located and set to clamp	cation 3 using both ha	ng both hands.	2. No wro 3. No dan 4. No wro Impor	ng use of parts ng use of tape laged clamp ng clamp position tant reminders/No se check the Clam start of assembly use of clamp.	np first		









	A	WORK INSTRUCTION						Effectivity Date:	May 15, 2025			
		Process Name/Title:	CLAMP ASSEMBLY PROCESS					Validity Date:	n/a			
		Model code/Part number:	311D / 7L0152-7024	Customer:	TRQSS	Car Model:	TOYOTA RAV 4	Document No.:		WI-ENG-PDE-1	258	
		Purpose:	□PROTOTYPE	PRE-LAUNCH	1	MASSPR	RO	Revision No.:	1	Page No.:	7 of 7	
PARTS:	1. As	. Assy parts						JIG:	n/a			

VISUAL INSPECTION/QUALITY CHECKPOINTS

CLAMP ASSY

7L0152-7024



- **Alignment**
- 1 Check the Clamp 2 No Missing Clamp
- (3) No Missing Tape (Blacktape)
- No Missing Spot inside tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.