


									Effectivity Date:				2023
			Process Name/Title: TAPING ASSEMBLY PROCESS Model code/Part number: 382D / 7N0185-7020B Customer: TRJ Car Model: TOYOTA-CAMRY					Validity Date:					
		7	Model code/Part number:	382D / 7N0185-7020B	Customer: TRJ	1		TA-CAMRY	Document No.:			WI-ENG-PDE-7	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSI	PRO		Revision No.:		1	Page No.:	1 of 5
PARTS:		Assy parts Black VM tube (Sunprene) ø9 L=1 Black tape		20±3mm					JIG:		n/a		
NO.		PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS	/PPE	QUALITY POINTERS			
NO.		P1 TABLE LAY-OUT		TABLE LAY-OUT Black VM tube (Sunprene) ø9 L=120±3mm Assy parts Black tape with holder				Safety Instr Be sure to required per protective eduring oper (gloves, fing etc.) Houseker 1. Maintain ar practice 2. Personal the workpl prohibited. Kyour loce Alert le For any troub the Assembly Supervisor Leader for im corrective a	wear rrsonal luipment ration er cots, eping d always 5's. hings on ace is eep it in ker. vel e, inform Assistant or Line mediate	1. No missing parts/tools 2. No excess parts/tools 3. No wrong position of parts/tools			
				Revision History					Prepared	l by R	eviewed by	Approved by	Noted by
11/24/23	1	Document purpose from prelaunch to masspro. Additional table layout and quality pointers. Improve work procedure due to improvement. Align quality checkpoints on finished assy parts. A. Arañes							n/a O'RIMLON		mf Hour		
10/24/23 0 Eff. Date Rev. No		Initial issu						n/a A.Hernar		Villanueva	A. Arados	n/a	
⊏II. Date	Rev. No	Details of Change					Reviewed	d Approved Noted Est. Date: Octo			er 24, 2023		










				WORK INS	Effectivity Date:	November 24, 2023				
		C	Process Name/Title:	TAPING ASSEMBLY PROCESS				n/a		
			Model code/Part number:	382D / 7N0185-7020B	Customer: TRJ	Car Model: TOYOTA-CAMRY	Document No.:		WI-ENG-PDE-7	'41
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 5
	1									
PAR	TS:	n/a					JIG:	n/a		
	QUALITY CHECKPOINTS									

P1

7N0185-7020B



- **No Missing Tape** (on COT to wire and taping to sunprene tube)
- (2) No Missing VM tube (Sunprene)
- **No Deformed Terminal**

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.