

	Process	Name/ Title:				
	PACKING INSTRUCTION		Document No:	WI-QAD-QAC-229		
7	WORK IN	STRUCTION	Effective Date:	September 22, 2023		
	Product Code/Name:	Customer Code:	Rev. No.: 0	Page 1 of 1		
	A7448C	TRQSS		rage I of I		

10.00	A/448C IRUSS								
Put Vinyl Sheet (1520 x 1500) inside carton box. Put first bdl of products. (25pcs.) Put second bdl on upper with opposite direction. Put second bdl on	No.		Work Procedure/ Illustration						
2 Put first bdl of products. (25pcs.) Put second bdl on upper with opposite direction.	1	(1520 x 1500)	Sheet (500)			50 Dim. 1131*781 1520*1500	25pcs*2bdls Qty. 1		
opposite direction.	2	Put first bdl of products. (25pcs.)							
	3	opposite direction.							
Fold the vinyl sheet Then close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box). Note: If need to attach 4M tag Put 4M tag at the left side	4	Then close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of	Note: If need						
mangin Jung My					Menzfih	May	Approve,		
0 Initial Issue M. Garcia D.Dadulla R. Pascua M. Garcia D.Dadulla							RI/Plasokua 3		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

