									Effectiv	Effectivity Date: July 21, 2					
		Process Name/Title:	ocess Name/Title: KITTING ASSEMBLY PROCESS							/ Date:		n/a			
		Product Name/Code:	480A	1	A7040E	Customer:	TRQSS		Docum	ent No.:		WI-ENG-PDE-3	04		
		Purpose:	PR	ОТОТҮРЕ		PRE-LAUNCH	MASSPRO		Revisio	on No.:	1	Page No.:	1 of 3		
		<u> </u>										<u> </u>			
PARTS:		assembled parts (Connecto Sf wires GR-B/W L=216±2r	tor 6188-0407(W), Clip type clamp 82711-1E360(W)) 2mm						JIG:	1. Insertio	1. Insertion jig with switch cover				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION								TOOLS/PPE		QUALITY POIN	TERS			
1		Connector setting to Insertion jig 6188-0407 (W)	Wire guide Holes Wire guide L 1. Press the using left to	e lock of i	B/W wire Button Press		Holes COOR OR OF (W) into jig using rentation.	NNECTOR LENTATION  Release  ight hand and	r pro	afety Instruction Be sure to wear required personal otective equipme during operation gloves, finger cots etc.)  Housekeeping Maintain and alway practice 5's. Personal things of the workplace is ohibited. Keep it in the workplace is ohibited. Keep it in the workplace is ohibited. Assembly Assistation and alway are to the workplace is ohibited. The workplace is ohibited. The workplace is ohibited. The workplace is ohibited. Assembly Assistation ader for immediation corrective action.	ays  in  1. Use the 2. No wron 3. No wron 4. No dam  Note for 1	provided jig per mod g orientation of connector guse of connector aged connector aged connector aged connector the process of Clip of chment	1 hole is open del lector		
					Revision History	1	1			Prepared by	Reviewed by	Approved by	Noted by		
07/21/21 1 10/23/18 0	illustrati	on and quality pointers. Change GL-COM-003 for Color Standar	e connector colo	or in accor	dance with color stand	/I-ENG-PDE-304). Improve process dardization for plastic parts (Please	M. Catapang C. Villar C. Ricafort W. Cart		. Arañes	Mm cutupe M. Catapang	C. Villanueva	A. Shimamura	A. Arzaes		
Eff. Date Rev. No	0		D	etails of C	Change		Revised Check	ked Approved	Noted E	st. Date:	October 23, 2018				

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

			WORK IN	Ef	Effectivity Date:		July 21, 2021				
		Process Name/Title:	KITTIN	Va	Validity Date:		n/a				
		Product Name/Code: 480A / A7040E Customer: TRQSS Docume						ocument No.:		WI-ENG-PDE-304	
		Purpose:	PROTOTYPE	PRE-LAU	PRE-LAUNCH MASSPRO		Revision No.:		1 Page No.	: 2 of 3	
PARTS:	n/a							JIG	1. Insertion jig wit	n switch cover	
NO.	Р	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/F	PPE	QUALITY POINTERS		
2	1	Wire Insertion to connector 6188-0407 (W)	1. Hold the insertion jig using left hand. Of the Black/White wire and insert to termisolt ① using right hand.  3. Get the Gray wire then insert to termisolt ② using right hand.	nal R	2. Press the button using right thur for Gray wire will be opened.  4. After insertion, push the lock using thumb and then hold the wires and out the connector from jig using right.	R R I I I I I I I I I I I I I I I I I I	n/a		Note: Please ho terminal during  1. No loose insert 2. No wrong inser 3. One by one ins 4. No deformed te 5. No wrong wire  Note: Refer to for Pull-Push p	on tion ertion arminal facing	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

		Effectivity Date:	July 21, 2021		
	Process Name/Title:	KITTING	Validity Date:	n/a	
	Product Name/Code:	480A / A7040E Customer: TRQSS Document			WI-ENG-PDE-304
	Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH ■ MASSPRO	Revision No.:	1 Page No.: 3 of 3
PARTS:	1. Assy parts 2. Black Corrugated tube (no slit) 9	Ø7 L=125±3mm		JIG	Locking jig     Terminal cover jig
NO.	PROCESS NAME	WORK PR	TOOLS/PPE	QUALITY POINTERS	
3	Connector lock	Before lock  After lock  1. Put thand the proper service of the pr	Locking Jig	NOTE: MANUAL LOCKING MAY CAUSE DAMAGED LOCK.  1. Use the provided locking jig per model 2. No unlock/half-lock connector	
4	Wire insertion to Black Corrugated tube Ø7 L=125±3mm (no slit)	1. Get the terminal cover jig using right hand then insert the GR and B/W wires.	2. Get the Corrugated Ø7 L=125±3mm (no slit) using right hand and insert the GR-B/W wires.  3. After insertion, remove the terminal cover jig using right hand.	Terminal Cover Jig	1. No wrong use of parts 2. No deformed terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY