

## Process Name/ Title: PACKING INSTRUCTION

Document No: WI

WI-QAD-QAC-173

WORK INSTRUCTION

Product Code/Name:

Customer Code:

Effective Date:

June 4, 2024

		F	Product Code/Name: <b>7L0084</b>	Customer Code: TRQSS	Rev. No.:	1	Page No	.: Page	e 1 of 1
No.	Work Procedure/ Illustration						Records/Remarks/ Quality Pointers		
1	1 Put Vinyl						Qty/box	50	25pcs *2bdls
	Sheet (1250 x inside carton	(1250)				Mat'l name	Dim.	Qty.	
	moide carton box.					DC carton	1131*781	1	
						$\sqrt{1}$	Vinyl sheet	1250*1250	1
						Vinyl bag	420*280	2	
2	Put first bdl of p (25pcs/bd						Note : 1 Step nur only in <b>QC</b>	\_\nber 5 is appoint is appoint in the second in the secon	plicable <b>ion.</b>
3	Put second bd other side with o direction (25p	opposite							
<u>1</u> 4	Fold the vinyl	sheet.							
(5)	Close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the left side of the front of the box).				d to attach 4M M tag at the rig	ht side			
						Prepare	Che	eck	Approve
						8/	-/~		M, /

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

1

Rev. no.

06/04/2024

Eff./Rev. Date

NBC (Philippines)

MASTER COPY

J. De La Cruz

Prepared

D.Dadulla

Checked

R.Pascua

Approved

Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture

of no. 1; Modify no. 4 and Addition of no. 5; Modify note.

Details of change

D.Dadulla

Established. date: June 19, 2020