Process Name/ Title: Document No: WI-QAD-QAC-266 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: July 2, 2024 Product Code/Name: Customer Code/ Customer Page No.: Page 1 of 1 Rev. No.: 7R0127 TRMX Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** (1) Qty/bo 50pcs*8 400 bdls X Mat'l Dim. Qty. Put Vinyl Sheet name (1250 x 1250) inside TRMX box. TRMX 544*370* 1 228mm box Vinyl 1250* 1 sheet 1250 2 343* Plastic vinyl bag of **Partitio** 50pcs × 4bdls 1 CSW assy n board 510 420* Vinyl 8 Put the products inside 280 bag the box (opposite direction per bundle) Note: (50pcs* 4 bundles) Step 5 is applicable only in QC FG inspection. For CSW process, use Oricon box 1st LAYER instead of TRMX box. (3) Layout partition board 4 Put another bundles inside the box (opposite direction per bundle) (50pcs* 4 bundles) **2ND LAYER** (5) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at Note : If need to attach 4M tag
Put 4M tag at the left side of the box right side of the box. Prepared by Checked by Approved by Noted by Change vinvl sheet size from 1520x1500mm to 1250 x 1250mm:Corre 07/02/24 S. Malabuyo R. Pascua em No. 4 to 4bundles. Transfer from WI-ENG-PDE-573. mardey

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in amy form, disclosure or publishing of this document or any information herein is strictly prohibited.

nitial Issue

Details of change

07/29/22



M.Ariola

J. Loterte

Checked

C. Villanueva

A. Arañes

6 Malabuyoo

N/A