			Process Name/Title:	WO	Effectivity Date: Validity Date:		October 21, 2024 n/a				
		H	Model code/Part number:	900B.910B / 7N0104	TAPING ASSEMBLY PROD I-7020C Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	20	Revision No.:	1	Page No.:	1 of 6
PARTS:								JIG: 1.Terminal cover jig			
N	0.	F	PROCESS NAME	V	WORK PROCEDURE/ ILLUSTR	ATION		TOOLS/PPE QUALITY POINTERS			
				Plack Cov	TABLE LAY-OUT	k SV tube (Vin		Safety Instruction Be sure to wear prescribed personal protective equipmer during operation (gloves, finger cots, etc.)	Docum	ent reference/ to WI-ENG-PDE- assembly proces	1136 for
1	ı	P1	Table Lay-out			5 L=64±3mm	Housekeep 1. Maintain and a practice 5's 2. Personal thin the workplace prohibited. Keep your locker		/s 1. No missii 2. No exces		
					Terminal cover jig	Black tap hold		Alert level For any trouble, inforr the Assembly Assistar Supervisor or Line Leader for immediate corrective action.	nt		
	L			Revision	n History			Prepared by	Reviewed by	Approved by	Noted by
			·			 					
10/21/24	1	Change	from Pre-launch to Masspro. Up	date Visual inspection/Quality checkpoi	ints.	D. Castillo C	C.Villanuev a A. Arañes	n/a			
10/17/24		Initial iss	ue.			D. Castillo C	C.Villanuev a A. Arañes	n/a catulo D. Castillo	C. Villanueva	A. Arañes	n/a
Eff. Date	Rev. No			Details of Change		Revised F	Reviewed Approved N	Noted Est. Date:	October 17, 2024		

NBC (Philippines)

MASTER COPY

			WORK INSTRU	JCTION			Effectivity Date:		October 21, 20	24
		Process Name/Title:	TAPING A		Validity Date:		n/a			
		Model code/Part number:	900B.910B / 7N0104-7020C	Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPF	RO	Revision No.:	1	Page No.:	2 of 6
PARTS:	1. Black 2. Assy	Corrugated tube (No slit)	Ø5 L=75±3mm 3. Black tape 4. Black SV tube (Vinyl) Ø5 L=64±3mm				JIG:	Terminal cover jig		
NO.	Р	ROCESS NAME	WORK PRO	CEDURE/ ILLUST	RATION		TOOLS/PPE	(QUALITY POIN	TERS
2		Wire insertion to Black SV tube (Vinyl) Ø5 L=64±3mm	L R	1. Get the Black using right hand hand.	SV tube (Vinyl) and insert B-B v	Ø5 L=64±3mm wires using left	n/a	1. No wrong	guse of part.	
3	P1	Wire insertion to Black Corrugated tube (No slit) Ø5 L=75±3mm	1. Get the terminal cover jig using right han then insert the B-B wires using left hand.	2. Get the right hand.	he Black COT ond and insert B-	R 25 L=75±3mm using B wires using left the terminal	TERMINAL COVER JIG		ng use of parts rmed terminal	

NBC (Philippines)
MASTER COPY

			WORK INSTRUCTION		Effectivity Date:		October 21, 20	24
		Process Name/Title:	TAPING ASSEMBLY I		Validity Date:		n/a	
		Model code/Part number:	900B.910B / 7N0104-7020C Customer: TR	RJ Car Model: LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A
		Purpose:	PROTOTYPE PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 6
PARTS:	1. Assy 2. Black	tape		JIG:	n/a			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILL	USTRATION	TOOLS/PPE		QUALITY POIN	TERS
4	P1	Taping 1 Black corrugated tube to Black SV tube (Vinyl) near connector	1. Fix the corrugated tul and SV tube (Vinyl) usin both hands. Make sure gap between corrugated tube and SV tube (Vinyl) 25±3mm 3. After taping and taping containing to the sure of the	2. Get the Black tape and start taping process using both hands.		1. Pleas measur measur 2. Must SV tube Docui 1. Pleas taping p 1. No flip 2. No pee 3. No loo 4. No mis 5. No wro	be no gap between a (vinyl). ment reference. se refer to WI-PRC procedure. -out tape el-off tape	verified tting the en COT and s:



WORK INSTRUCTION Effectivity Date: October 21, 2024										
		December 17:41			CESS		October 21, 2024 n/a			
		Process Name/Title:		IG ASSEMBLY PRO		Validity Date:				
		Model code/Part number:	900B.910B / 7N0104-70200	C Customer: TRJ	Car Model: LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 6	
	1									
PARTS:	1. Assy 2. Black					JIG:	n/a			
NO.	·		WORK F	PROCEDURE/ ILLUSTI	RATION	TOOLS/PPE	(QUALITY POIN	TERS	
5	P1	Taping 2 Black SV tube (Vinyl) to wire near connector	1. Hold SV tube (Vinyl) using left measure from SV tube (Vinyl) up connector 25±3mm. 25±3mm 25±3mm	smm	2. Get Black tape using right hand, hold the SV tube (Vinyl) (ø5 L=64±3mm) using left hand then fold the vinyl tube and start taping using right hand.	6 7 8 9 (1) 1 2 3 4 5 6 7 8 9 (1) 1 2 3 4 7	1. Please measure measure Docum 1. Please taping pressure 2. No peel 3. No loose 4. No miss 5. No wron	ent references. e refer to WI-PRO-cocedure. Dut tape -off tape e tape	verified tting the	



			WORK INS	Effectivity Date:	October 21, 2024								
		Process Name/Title:	TAPIN	Validity Date:		n/a							
		Model code/Part number:	900B.910B / 7N0104-7020C	Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	1	Page No.:	5 of 6			
PARTS:	1. Assy parts 2. Black tape JIG:								n/a				
NO.	F	PROCESS NAME	TOOLS/PPE	(QUALITY POIN	TERS							
6	P1	Taping 3 Black Corrugated tube to Wire near Connector	25±3mm 25±3mm 25±3mm 25±3mm 0~5mm	and ta	2. Measure fror to connector 25 continue the tall both hands.	m end of the COT up	MEASURING TAPE 6789 1234 5 6789	1. Please measure measure measure measure 1. Please taping proceeds 1. No flip-2. No peel 3. No loos 4. No miss 5. No wron	pent references e refer to WI-PRO- ocedure. out tape -off tape e tape	verified tting the			




		WORK INSTRUCTION							Effectivity Date:	October 21, 2024			
		Process Name/Title:	Т	Validity Date:	n/a								
		Model code/Part number:	900B.910B / 7N0104-	7020C	Customer:	TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-11	37A	
		Purpose:	PROTOTYPE		PRE-LAUNCH		MASSPE	0	Revision No.:	1	Page No.:	6 of 6	
PARTS:	1. Ass	sy parts	٨						JIG:	n/a			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P1

7N0104-7020C



(1) (2) (3)

No Missing Tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY