
			WORK INSTRUCTION Process Name/Title: CLAMP ASSEMBLY PROCESS							October 30, 2024		
Ы			Process Name/Title:		dity Date:		n/a					
		7	Model code/Part number:	011B / 7M0364-7021B		Car Model: TOYOTA CAMI		ument No.:		WI-ENG-PDE-1		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Rev	rision No.:	1	Page No.:	1 of 5	
PARTS:		1. Assy	parts;Clamp 82711-52090	0 (W); Black tape [2pcs]; Blue tape	/); Black tape [2pcs]; Blue tape				1. Clamp a	1. Clamp assembly jig		
N	0.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE		QUALITY POINTERS		
		Clamp	Table Lay-out		TABLE LAY-OUT	Clamp 82711-52090 (W)/ Clamp tray		Be sure to wear prescribed person protective equipme during operation (gloves, finger cot etc.)	al ent s, Docum 1. Refer t	Document reference/s: 1. Refer to WI-ENG-PDE-1144A-B for		
1	ı			Assy parts		Clamp assembly jig	:	Housekeeping Maintain and always practice 5's. Personal thick site workplace is prohibited. Keep it your locker.	on 1. No missing parts/tools 2. No excess parts/tools			
				Black tape/Ta	pe holder Blue ta	pe/ Tape holder	th	Alert level for any trouble, info the Assembly Assist Supervisor or Line Leader for immedia corrective action.	tant e ate			
	Revision History					ļ.	Prepared by	Reviewed by	Approved by	Noted by		
10/30/24	1	Change fr	om Pre-launch to Masspro.			D.Castillo C.Villanueva A. Arañes	N/A	+				
10/30/24	0	Initial issu	ie.	n Taping assembly process due to process impro	vement.	D.Castillo C.Villanueva A. Arañes D.Castillo C.Villanueva A. Arañes	N/A	D. Castillo	C. Villanueya		N/A	
Eff. Date	Rev. No			Details of Change		Revised Reviewed Approved	Noted	Est. Date:	October 22, 2024	A. ALERIUS	IV/A	

			WORK INS	STRUCTION		Effectivity Date:	October 30, 2024		
		Process Name/Title:	CLAM	IP ASSEMBLY PRO	Validity Date:	n/a			
		Model code/Part number:	011B / 7M0364-7021B	Customer: TRJ	Car Model: TOYOTA CAMRY	Document No.:		WI-ENG-PDE-11	53
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 5
PARTS:	1. Clamp 82711-52090 (W) 2. Black tape[2pcs]			JIG:	1. Clamp assembly jig				
NO.	F	PROCESS NAME	WORK	TOOLS/PPE	QUALITY POINTERS				
2	Clamp	Clamp setting	1. Get 2pt location 1	and 2 using both hands.	W) using both hands then set to		Importa 1. Please start of as clamp. 1. No wron 2. No dam 3. No miss	clamp Illustration	clamp lote/s: iirst before rong use of

	_		WORK INS	Effectivity Date: October 30, 2024					
		Process Name/Title:	CLAM	Validity Date: n/a					
		Model code/Part number:	011B / 7M0364-7021B Customer: TRJ		Car Model: TOYOTA CAMRY	Document No.:	WI-ENG-PDE-1153		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 5
PARTS:	Assy parts Blue tape					JIG:	I. Clamp assembly jig		
NO.	F	PROCESS NAME	WORK F	TOOLS/PPE	(QUALITY POINT	ΓERS		
3	Clamp	Clamp assembly	CONNECTOR SETTING 1. Get the assy parts and set into jig. (Scorrect setting). First, set the connector Receiver base 1 and lock. Last, set the within the stopper then press by toggle process if sequence light in location 1 sequencountered abnormality, STOP and in attention of the leader. WAIT for further continue the process. Continue if the set 1 was ON. 3. Hold the tape on clamp location 1 are hands. Make 3 windings then cut the button after taping. Continue the process location 2 was ON.	CLAMP ON was ON. nce light is ON. If nmediately CALL the r instruction then equence light of location and start taping using both tape. Press the SW	3 Spot taping	tape. Press the SW ess if sequence light on ing on location 3 using the color sensor detected removing of harness from	1. Make sterminals. 2. Make 2 1. No loose 2. No dama 3. No miss 4. No miss	ed tape	n stopper and





		WORK INSTRUCTION						Effectivity Date:	October 30, 2024			
		Process Name/Title:	CLAMP ASSEMBLY PROCESS						Validity Date:	n/a		
		Model code/Part number:	011B / 7M0364-702	1B	Customer: TF	RJ	Car Model: T	OYOTA CAMRY	Document No.:		WI-ENG-PDE-1	153
		Purpose:	PROTOTYPE		PRE-LAUNCH		MASSPRO)	Revision No.:	1	Page No.:	5 of 5
	1									1		
PARTS:	1. Assy	parts							JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7M0364-7021B



1

No Wrong Facing of Clamp



No Missing Tape (Black Tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.