			WORK INSTRUCTION											March 14, 2025							
			Process Name/Title:			TAP	ING ASS	EMBLY P	ROCESS			Validity Date:		n/a							
			Model code/Part number:	PRE-ASSY		SSY	Customer: -		Car Mode	Car Model:		Document No.:		WI-ENG-PDE-1151							
			Purpose:		PROTOTYPE		☐ PRE-	LAUNCH	■ MAS	SPRO		Revision No.:	2	Page No.:	1 of 7						
PARTS:		Based on Part number Comparison			ı Table						JIG: n/a										
NO.		Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POINTERS									
		P1	Table	Part number Comparison Table						Safety Instruction Be sure to wear required personal protective equipmer during operation (gloves, finger cots, etc.)	Document reference/s: 1. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance										
				No.	Part number	Wire Color	Wire Length	SV tube Color	SV tube length	Tape Color	Page No.	Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.	ys	No deformed terminal No wrong usage of parts							
				1	75S744-7051	GR/B	120mm	White	ø3; 71±3mm	Sky Blue	Pg. 2-4										
1				2	75\$834-7051	GR/B	120mm	White	ø3; 71±3mm	Sky Blue	Pg. 2-4		1. 140 00101								
				3	75V076-7011	GR/B	120mm	White	ø3; 71±3mm	Sky Blue	Pg. 2-4		_								
				2 4	75V117-7111	L	89mm	Black	ø3; 25±3mm	Black	Pg. 5-7	Alert level For any trouble, infor									
																			the Assembly Assista Supervisor or Line Leader for immediate corrective action.		
						Davisias Histor															
	Revision History								Prepared by	Checked by	Reviewed by	Approved by									
03/14/25	2	2 Inclusion of 75V117-7111 on the Part number Comparison table and Taping assembly process. D. Castillo J.Loterte Villanueva A. Arañes																			
02/05/25	1	Inclusion of 75V076-7011 on the Part number Comparison table. M. Ariola n/a Villanueva A. Arañes Initial issue. Separate process. Inclusion of common models C.								ALT											
11/11/24	0	D. Castillo n/a Villanueva A. Arañes / D. Castillo J.L.Verte / C. Villan							C. Villanueva	A. Asseries											
Eff. Date	Rev. No	Rev. No Details of Change Revised Checked Reviewed Approved Est. Date: November 11, 2024																			

WORK INSTRUCTION Effectivity Date:									5	
		Process Name/Title:		Validity Date:	March 14, 2025 n/a					
		Model code/Part number:	TAPING ASSEMBLY PROCESS PRE-ASSY Customer: - Car Model: -			Document No.:	WI-ENG-PDE-1151			
		Purpose:	□ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	2 of 7	
		Purpose.	☐ PROTOTIFE	☐ PRE-LAUNCH	■ WASSPRO	INEVISION NO		Fage No	2 01 7	
PARTS:	1. Base	d on Part number Compariso	n Table			JIG:	n/a			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
2	P1	Wire Insertion to SV tube (Vinyl)	1. Get the wire us the wire.	sing left hand. Get 1 pc of	R R SV tube (Vinyl) using right ha	R and then insert		rmed terminal g usage of parts		

			WOF	Effectivity Date:	March 14, 2025						
		Process Name/Title:	7	TAPING ASSEMB	LY PROC	ESS		Validity Date:	n/a		
		Model code/Part number:	PRE-ASSY	Customer: - Car Model:		Car Model:	ı	Document No.:	WI-ENG-PDE-1151		
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	I	MASSPRO		Revision No.:	2	Page No.:	3 of 7
PARTS:	1. Assy 2. Sky I							JIG:	n/a		
NO.		PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	QUALITY POINTERS		
NO.	'	ROCESS NAME					TOOLS/PPE	QUALITY FOINTERS			
			9 50	36±2mm 9 50 1 2 3 4 5 15±3mm				6. No wron		-off tape e tape sing tape ng use of tape ng dimension	
3	P1	Taping 1 SV tube (Vinyl) to Wire near terminal	L R taping direct	ction	R	2. Get the Sky Blue tape, position the tape to White SV tube. Make 1 wind only using both hands.	WRO	ONG POSITION OF END TAPE	8. No insu	MEASURING	վարարարարարար 5 6 7 8 9 մաքանագարտականու
			36±2m 30±2mm		Measure f terminal 3 tape up to Then mak both hand Note: Las and end to	t wind must be slanted ape must be within the toverlapped to first	First wind End tape		Important reminders and note/s; 1. USE SKY BLUE TAPE only. 2. Please use calibrated/verified measuring tape when getting the measurement.		

	_		WORK INSTR	Effectivity Date:	March 14, 2025					
		Process Name/Title:	TAPING	Validity Date:	n/a					
		Model code/Part number:	PRE-ASSY	Customer: -	Car Model:		Document No.:	WI-ENG-PDE-1151		
		Purpose:	☐ PROTOTYPE ☐	☐ PRE-LAUNCH ■ MASSPRO		Revision No.:		2	Page No.:	4 of 7
	4 4									
PARTS:	1. Assy 2. Sky						JIG:	n/a		
NO.		PROCESS NAME	WORK PRO	TOOLS/PPE	(QUALITY POIN	TERS			
3	P1	Taping 1 SV tube (Vinyl) to Wire near terminal (Continuation)	4. Conduct proper pressing of end tape using left hand (top part). 15±3mm 7. After taping, check the dimension, telegraphs of the dimension	using left hand (Mi	ddle part).	using left hand	B	6. No wron 7. No defor 8. No insuf 6 7 8 Importat 1. USE 5 2. Please	off tape e tape ing tape g use of tape g dimension med terminal ficient tape MEASURING T 9 1 2 3 4 WATH A CALL OF TAPE THE	nd note/s;





