WORK NOTRUCTION															
			WORK INSTRUCTION					Effectivity Date:			May 18, 2022				
K)			Process Name/Title:	COT SLIT-IN PROCESS					Valid	Validity Date:		n/a			
			Model Code/Product Number:	COMMON	Customer:	NBS	NBS		Document No.:			WI-ENG-PDE-531			
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH		MASSPRO		Revis	sion No.:		0 F	Page No.:		1 of 1
	1										1	I			
PARTS:		1. Corruç	gated tube							JIG	1. Slitting Jig				
NO.		PR	OCESS NAME	WORK PROCEDURE/ ILLUSTRATION				Т	OOLS/P	PE	QUALITY POINTERS				
1		n/a Slit-In Process		2. Get the corrugated tube and insert to slitting hole using right hand. Note: Use the corresponding jig for each corrugated tube (Ø7 & Ø5). 25±3mm 25±3mm 25±3mm 3. Confirm slit in measurement 25±3mm.			2. Personal things			Note: For NBS support products only. 1. No wrong dimension of slit. 2. No double slit 3. No damage COT					
	I			Revision Histor	.,					Prepare	welst	Reviewed by	Approved	#	Noted by
05/18/22	0							C.Villanueva	A.Arañes	M,Ari	ola	J. Louerte	C. Villanu	eva	A.Aranes
Eff.Date	Rev.No			Details of Change		Revi	sed Reviewed	Approved	Noted	Est. Date:)	May 18, 2022			

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY