

No.

Process Name/ Title: **PACKING INSTRUCTION**

Document No:

Effective Date:

0

WI-QAD-QAC-256

April 24, 2024

Records/Remarks/

WORK INSTRUCTION Product Code/Name: 7L0036

Work Procedure/ Illustration

Customer Code: **TRQSS**

Rev. No.:

Page No.:

Page 1 of 1

1	Put Vinyl Sheet (1520 x 1500) inside carton box.



Quality Pointers								
Qty/box	100	50pcs * 2bdls						
Mat'l name	Dim.	Qty.						
DC carton	1131*781	1						
Vinyl sheet	1520*1500	1						
Vinyl bag	420*280	2						

Put first bdl of products. (2) (50pcs/bdl)





Note:

Step number 4 is applicable only in QC FG Inspection.

Put second bdl on (3) upper with opposite direction. (50pcs/bdl)



(4) Fold the vinyl sheet then close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the left side of the front of the box).







Note: If need to attach 4M tag Put 4M tag at the right side

						Prepare	Check
						10-	
						Mary	Mus
04/24/2024	0	Initial Issue	A. De Chavez	D. Dadulla	R. Pascua	A. De Chavez	D. Dadulla
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established date:	April 24, 2024

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

