
				Effectivity Date:	June 11, 2024						
			Process Name/Title:	CLAN	MP ASSEMBLY PROC	CESS	Validity Date:	n/a			
	-1		Model code/Part number:	ES1 / 7N0165-7020A	Customer: TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-8	20	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 6	
PARTS:		1. Assy parts: Clamp 82711-1682		0 (BR) ; Gray tape (10mm)		JIG:	Clamp assembly jig with locking jig		ocking jig		
NC	Э.	Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POINTERS		
1		CLAMP	Table Lay-out	Clamp 82711-16820 (I	Assy parts 1	Bando gun	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action. BANDO GUN		ing parts/tools sss parts/tools		
				Revision History			Prepared by Re	eviewed by	Approved by	Noted by	
							- Course L	out Tillow	AND		
06/11/24		Initial issu	ie.			D.Castillo C. Villanueva A. Arañes r	n/a D. Castillo C.	Villanueva	A. Araños	n/a	
Eff. Date	Rev. No			Details of Change		Revised Reviewed Approved No	oted Est. Date: June 1	11, 2024			

			WORK INS	Effectivity Date:		June 11, 2024			
		Process Name/Title:	CLAM	Validity Date:		n/a			
		Model code/Part number:	ES1 / 7N0165-7020A	Customer: TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-82	:0
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6
PARTS:	1. Clamp 82711-16820 (BR)					JIG:	1. Clamp a		
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS		
2	CLAMP	Clamp setting	1. Great to		82711-16820 (BR) RO (BR) using right hand then h hands.		82711-16 Importa 1. Please start of a of clamp. 1. No wron	nt reminders/No check the Clamp ssembly to avoid g use of clamp aged clamp	-26380 (BR) ote/s: first before

			Effectivity Date:	June 11, 2024							
		Process Name/Title:	Validity Date:	n/a							
		Model code/Part number:	ES1 / 7N0165-7020A	Customer:	TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-	820	
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPRO	Revision No.:	0	Page No.:	3 of 6	
PARTS:	1. Assy parts					JIG:	1. Locking Jig				
NO.	ı	PROCESS NAME	WORK F	WORK PROCEDURE/ ILLUSTRATION				QUALITY POINTERS			
3	CLAMF	Connector Lock	CROS NG Unlock Before Pro	SS SECTION NG Half-lock	using r lock us lock if p	Fully locked	LOCKING JIG	1. Use the 2. No unio	ant reminders/i	Y CAUSE jig per model inector	

	June 11, 2024								
		Process Name/Title:	CLAM	Validity Date:	n/a				
		Model code/Part number:	ES1 / 7N0165-7020A	Customer: TRJ C	ar Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-8	20
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 6
PARTS:	1. Assy 2. Gray			JIG:	Clamp assembly jig				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						(QUALITY POIN	ΓERS
4	CLAM P ASSY	Clamp Assembly	Connector setting Receiver base 1 Color sensor Gray tape only 1. Get the assy parts and set into jig. setting of harness). First, set the constitution of the const	Spot taping Spot taping (See above picture for correct connector 7C83-5524-70 (Y) to e harness in jig then set the PCE Toggle clamp. Continue if the	2. Initially tighten the band clamboth hands.	thand then cut the band hands. Press the SW e sequence light on then conduct 3 windings in hands. Color sensor etects Gray tape. Press o sound will be heard	Importa 1. Make s and PCB. 2. Green and minin If exceed/ tape cond 1. No loose 2. No dam 3. No miss	ant reminders/Notation and indicates both and dimension of a fact that aged clamping parts BANDO GUN ILLUSTRATION OF THE AND	Note/s: In stopper In maximum In end tape. Inark, end Inark, end Inark






			Effectivity Date:	June 11, 2024					
		Process Name/Title:	CLAM	IP ASSEMBLY PROCI	Validity Date:	n/a			
		Model code/Part number:	ES1 / 7N0165-7020A	Customer: TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-8	20
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 6
PARTS:	1. Assy parts				JIG:	n/a			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7N0165-7020A









NO GOOD

- No Unlock/ Half Lock Connector
 Check the CONNECTOR LOCK if
 properly locked.
 - No Wrong Insert

- (3) No Terminal Backing out
- 4 No Missing Parts
- No Missing tape (SV tube (Vinyl) to Wire; COT to SV tube (Vinyl); COT to wire near connector
- 6 No Missing Clamp
 - 7 No Missing Spot tape (Gray tape)
 - 8 No Damaged PCB

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.