


Process Name/Title:		Danisa ant Na	WI-PRO-ASY-001B	
SUB-ASSEMBLY TAPING PRO	CEDURE (VT to wire and COT to VT)	Document No:		
WORK I	NSTRUCTION	Effective Date:	April 29, 2025	
Product Code/Name:	Customer Code:	Day No. 2	Daga Na . 4 of 4	



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.




Process Name/Title:
SUB-ASSEMBLY TAPING PROCEDURE (VT to wire and COT to VT)

WORK INSTRUCTION

Product Code/Name:

Customer Code:

Rev.No.: 3 Page No.: 2 of 4



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



Process Name/Title:
SUB-ASSEMBLY TAPING PROCEDURE (VT to wire and COT to VT)

Document No:

WI-PRO-ASY-001B

WORK INSTRUCTION

Effective Date:

April 29, 2025

Product Code/Name: COMMON

Customer Code:

Rev.No.:

Page No.:

3 of 4

No.


Work Procedure / Illustration

Records/Remarks/ Quality Pointers

5 COT to VM Sunprene tube 19mm



1. <u>1 Wind</u> pre tape in the middle of cot and sunprene tube



2. shift the tape


1/2 shifting going to sunprene tube must be 19mm



3. make <u>1 Wind</u> before shifting



4. shift the tape 1/3 shifting going to cot




6. make <u>2</u> <u>winds</u> before end of tape



3

7. conduct 3x pressing at the end of tape to avoid peel off.



- 1. No insufficient taping
 - 2. No loose tape
 - 3. No tape peeling
 - 4.No flip-out tape

COT to VM Sunprene tube 25mm

6



1. <u>1 Wind</u> pre tape in the middle of cot and sunprene tube



2. shift the tape

1/2 shifting
going to
sunprene tube
must be 25mm



3. make <u>1</u>
<u>Wind</u> before shifting



4. shift the tape

1/3 shifting
going to cot



5. shift the tape

1/2 shifting

upward until it
reach 25mm



6. make <u>2</u> <u>winds</u> before end of tape



7. conduct 3x pressing at the end of tape to avoid peel off.



25mm 25mm

- 1.No insufficient taping
 - 2. No loose tape
- 3. No tape peeling

4.No flip-out tape

Types of Vinyl Tube



SV Vinyl tube Hard type

VM Sunprene tube Soft type

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



Process Name/Title: SUB-ASSEMBLY TAPING PROCEDURE (VT to wire and COT to VT)			Document No:		WI-PRO-ASY-001B	
WORK INSTRUCTION			Effective Date:		April 29, 2025	
Product Code/Name:	Customer Code:	Rev.No.:	3	Page No.:	4 of 4	

COMMON **COMMON** Records/Remarks/ **Work Procedure / Illustration** No. **Quality Pointers Appearance after Taping** 1/3 shifting Vinyl tube to **Crimped Wire** (All dimension) 1. No insufficient taping 2. No loose tape VM Sunprene tube 3. No tape peeling 4.No flip-out tape Applicable to 1. 2 Winds before shifting 3. make 3 Winds before end of tape 2. shift up 1/3 going **Types of Vinyl Tube** Steering process Conduct 3x pressing at the end of (width must be depends (width must be depends on stated in to crimped wire SV Vinyl tube Taping to prevent peel off and on stated in WI) WI) Hard type loose tape using left thumb. VM Sunprene tube Refer to WI-PRO-COM-015 Soft type

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.