
				WORK INST	Effectivity Date:	July 15, 2024					
		Process Name/Title:		OFFLIN	IE ASSEMBLY PRO	CESS	Validity Date:	n/a			
		Model code/Part number:	NB8 /	7N0209-7020a	Customer: TRJ	Car Model: SUBARU-LEGAC	Y Document No.:		WI-ENG-PDE-94	9	
		Purpose:	PROTOTY	YPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 6	
PARTS:		nector 7C83-5524-70 (Y) ck Corrugated tube (No Slit)	Ø5 L=353±4mm	3.	AVSSf 0.3 Black/White L= 4. AVSSf 0.3 White		JIG:	Insertion Locking			
NO.	F	PROCESS NAME		WORK P	ROCEDURE/ ILLUSTF	RATION	TOOLS/PPE	QUALITY POINTERS			
1	offline	Table Lay-out		Connector 7C83-5524-70 (Y)		Black Corrugated tube (No Slit) Ø5 L=450±3mm Hotmelted Wire	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. No wron 2. No exce	g use of parts ss/lacking of parts		
				Revision History			Prepared by R	Reviewed by	Approved by	Noted by	
07/15/24 0	Initial iss	ue.				A.Hernandez C. Villanueva A. Arañes	Okimum de /	/out/) for	AArades	n/a	
Eff. Date Rev. No			Details o	f Change		Revised Reviewed Approved		15, 2024	7117433000	.,,	
•				•							

				STRUCTION INE ASSEMBLY PRO		Effectivity Date:		July 15, 2024	
		Process Name/Title:		Validity Date:	n/a				
	5	Model code/Part number:	NB8 / 7N0209-7020a	Customer: TRJ	Car Model: SUBARU-LEGACY	Document No.:		WI-ENG-PDE-94	19
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6
PARTS:	1. Conr 2. Black	ector 7C83-5524-70 (Y) c Corrugated tube (No Slit)	Ø5 L=353±4mm	JIG:	1. Insertion jig				
NO.	Р	ROCESS NAME	WORK	PROCEDURE/ ILLUSTR	TOOLS/PPE	QUALITY POINTERS			
2	offline	Connector setting to Insertion jig 7C83-5524-70 (Y)	Push button Lower wire guide	Lock Lock I-mark Press I hand. Get the ent to insertion jig ar insertion.	Connector Setting Release 2. Press the lower wire guide using right hand. Slot for White wire will be open.	n/a	1. No v	wrong orientation of connector Orientation (Illustration k. is n. GOOD	f connector
3		Wire insertion W-B/W to Black Corrugated tube (No Slit) Ø5 L=353±4mm		L=353±4mm using I	Corrugated tube (No Slit) Ø5 eft hand. Get the W and B/W wires d insert to the Black Corrugated =353±4mm.			g use of parts med terminal	



	WORK INSTRUCTION Effectivity Date: July 15, Process Name/Title: OFFLINE ASSEMBLY PROCESS Validity Date: n/a								
		Process Name/Title:			Validity Date:		n/a		
		Model code/Part number:	NB8 / 7N0209-7020a Cust	omer: TRJ	Car Model: SUBARU-LEGACY	Document No.:		WI-ENG-PDE-9	49
		Purpose:	□PROTOTYPE □ PRE-I	AUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 6
PARTS:	2. AVSSf 0.3 White L= 450±2mm								
NO.	F	PROCESS NAME	WORK PROCED	URE/ ILLUSTR	ATION	TOOLS/PPE	QUALITY POINTERS		
4	offline	Wire Insertion to connector 7C83-5524-70 (Y)	White 1. Get the White wire and insert to terminal slot 1 using right hand. Black/White 2 3. Get the Black/White wire and insert to terminal slot 2 using right hand.	2. After insertion right thumb. Slot 4. After insertion, hand and then he	of White wire, press the button using for Black/White wire will be open. press the insertion jig lock using left old the wire and gently pull out the gusing right hand.		Connect N	nt references:	GOOD


			WORK INS			Effectivity Date:	July 15, 2024			
PARTS: 1 NO.		Process Name/Title:		IE ASSEMBLY PRO		Validity Date:	n/a WI-ENG-PDE-949			
	57	Model code/Part number:	NB8 / 7N0209-7020a	Customer: TRJ	Car Model: SUBARU-LEGACY	Document No.:				
		Purpose:	PROTOTYPE	□PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 6	
	1. Assy	part PROCESS NAME	WORK B	PROCEDURE/ ILLUST	PATION	JIG: TOOLS/PPE	1. Locking	jig QUALITY POIN	TEDS	
NO.	-	ROCESS NAME	WORK P	KOCEDOKE/ ILLUSII	RATION	100L3/FFE	<u>'</u>	QUALITY FUIN	IIEKO	
5	offline	Connector Lock	1. Hold the connector using right hand and insert into locking jig. Push 2x to lock the connector properly 2. Ensure that connector is in locked of sequence illustrated.	NG	S SECTIONAL VIEW NG GOOD Half-locked Fully locked		2. No unlo 3. No dam Im 1. Manu connecte 2. Do no damage GOO LO Docum 1. Refer	ot exert extra force d of connector.	rs/Notes: use damaged It may cause NG JNLOCK/ ALF-LOCK	



NB									Effectivity Date:		July 15, 2024		
	Pro	cess Name/Title:		OF	FLINE A	ASSEMBLY PR	OCESS		Validity Date:		n/a		
	Mod	del code/Part number:	NB8	/ 7N0209-702	0a	Customer: TRJ	Car Model:	SUBARU-LEGACY	Document No.:		WI-ENG-PDE-9	49	
	Pur	pose:	□ PRO	OTOTYPE		PRE-LAUNCH	MASSPR	0	Revision No.:	0	Page No.:	6 of 6	
									1		_		
PARTS:	n/a								JIG:	n/a			
					VISUAI	L INSPECTION/Q	UALITY CHEC	KPOINTS					
OFF	I INI					711	0	7020					
OFF	LLIIA	-					UZUS	-7020	a				







- 1 No Unlock/Halflock Connector
- 2 No Terminal Backing Out

3 No Wrong Insertion

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.