			WORK INSTRUCTION								Effectivity Date:			June 11, 2024		
			Process Name/Title: TAPING ASSEMBLY PROCESS							Validit	y Date:		n/a			
			Model code/Part number:	ES1 / 7M0503-7020A	20A Customer: TRJ Car Model: SUBARU-FOREST				-FORESTE	<b>R</b> Docur	ocument No.:		WI-ENG-PDE-199A			
			Purpose:	PROTOTYPE	PRE-LAUNCH		MASSP	PRO		Revisi	ion No.:		7	Page No.:	1 of 3	
PARTS:		Assy parts; Black tape								JIG:		n/a				
NO.		F	PROCESS NAME	✓7 WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		C	QUALITY POI	NTERS			
<b>NO.</b> 1		P1	Table Lay-out	TABLE LAY-OUT  Assy parts  Black tape/ Tape holder				Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping  1. Maintain and always practice 5's. 2. Personal things on		al ent says says says says says says says say	Document reference/s: 1. Refer to WI-ENG-PDE-558 OFFLINE ASSEMBLY PROCESS.  1. No missing parts/tools 2. No excess parts/tools					
				Revision History							Prepared by	Rev	iewed by	Approved by	Noted by	
06/11/24	7	7 Transfer Taping 2 to P2 (WI-ENG-PDE-model "SUBARU-FORESTER".		-199B). Update table lay-out and visual inspection/quality checkpoints. Inclusion of car		D.Castillo	а	A. Arañes	n/a							
04/28/23	6	Inclusion of quality checkpoints.					g	а	C ) (illeeveev	n/a	Jestius	11.	h:#	AND TO		
11/04/22	5	Improve	notes/references and quality points	ointers in process 1, 2 and 3 as document improvement.		M.Catapan g Revised	J.Loterte	а	Arañes	D. Castillo / .		J. Loterte C. Villamaeva A. Arañes		A. Arañes		
Eff. Date	Rev. No	Details of Change						Reviewed	Approved N	proved Noted Est. Date: July			2018			


CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



			WORK INS	Effectivity Date:	June 11, 2024						
		Process Name/Title:	Validity Date:	n/a							
		Process Name/Title: TAPING ASSEMBLY PROCESS  Model code/Part number: ES1 / 7M0503-7020A Customer: TRJ Car Model: SUBARU-FORESTEF						WI-ENG-PDE-199A			
		Purpose:	PROTOTYPE	PRE-LAUNG		MASSPRO	Revision No.:	7	Page No.:	2 of 3	
PARTS:	1. Assy 2. Blac	parts k tape					JIG:	n/a			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS			
2	P1	Taping 1 Black SV tube (Vinyl) to wire near connector	25±3mm 25±3mm 25±3mm 20±3mm 1 2 3 4	R	2. Get the Blathen start taphands.	e SV tube (Vinyl) using left hand then from end of tube up to edge of '25±3mm using both hands.  ack tape using right hand ing process using both  r taping, check the measurement ping condition.	Measuring tape  6 7 8 9 10 1 2 3 4 5 6 7 8 9  white last the state of	1. Pleameasumeasumeasumeasumeasumeasumeasumea	-off tape e tape	verified etting the	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.





CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY