

				WORK INS	Effectivity Date:	March 7, 2025				
			Process Name/Title:	TAPIN		Validity Date:	n/a			
	-11		Model code/Part number:	559D / 7N0237-7020B	Customer: TRJ	Car Model: TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-10	64B
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 6
PARTS:	1	1. Assy	parts, Black SV tube (vinyl) of	p5 L=490±3mm; Brown tape	JIG: n/a					
N	Э.	F	PROCESS NAME	WORK	TOOLS/PPE QUALITY POINTERS					
		P2		Black SV tube (vi L=490±3mr			required personal protective equipment	1. No wrong use of connector 2. No damaged connector 3. No wrong insert 4. One by one insertion 5. No deformed terminal 6. No wrong terminal Orientation Important reminders/Note/s: 1. Make sure wires are properly inserted. Conduct Pull-Push-Pull-Push after insertion. Do not exert extra force. 2. Please hold the wire near terminal during insertion. Document references: 1. Refer to WI-PRO-CNC-017 for Wire		
1			Table lay-out	TOPENATE	Accuments		Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.			
					Assy parts Tap	Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	and Strip length tolerance. 2. Refer to GL-PRO-ASY-029 Push procedure.			
				Prepared by C	hecked by	Reviewed by	Approved by			
							.,			
03/07/25	0 E			64 due to new process distribution. Change from	Pre-launch to Masspro. Additional	M. Ariola J. Loterte C. Villanueva A. A	nrañes M. Ariona J	. Loverte	C. Villanueva	A. Arañes
Eff. Date	Rev. No			Details of Change		Revised Checked Reviewed App	roved Est. Date: March	7, 2025		







			WORK INSTRUC	Effectivity Date:		March 7, 2025						
		Process Name/Title:	TAPING AS	Validity Date:	•		n/a					
		Model code/Part number:	559D / 7N0237-7020B Customer: TRJ Car Model: TOYOTA HI-ACE				Document No.:		WI-ENG-PDE-1064B			
		Purpose:	☐ PROTOTYPE ☐ P	PRE-LAUNCH	■ MASSP	RO	Revision No.:		0	Page No.:	4 of 6	
PARTS:	Assy parts Black Tape						JIG:		n/a			
NO.	F	PROCESS NAME	WORK PROC	TOOLS/P	PE	QUALITY POINTERS						
			taping direction Tape shifting 1/2		8. Make winding width m 20±3mr	gs, ust be	Document reference/s: 1. Refer to WI-PRO-ASY-001C for taping procedure (special). Important reminders/Note/s: 1. Use <u>yellow tape</u> for easy visualization of tape shifting, but					
4	P2	Y-Taping (continuation)	Taping direction Tape shifting 1/2					tape cutting		actual should be BLACK TAPE. 2. Please use calibrated/verified measuring tape when getting the measurement. 1. No loose tape 2. No flip-out tape 3. No peel-off tape 4. No wrong use of tape 5. No wrong dimension-out tape 6. No exposed wire		
			9. Winding the tape 1/2 shifting going to the side until it reach the other side of tube	right 10. Mak	e 3 winds, wie	dth must be 20±3mm. Th	en cut the tape.		7. No gap	between tubes	_	
			11. conduct proper pressing of end tape using left hand (top part). Note: Reference only.	12. conduct proper using left hand (Mic			oroper pressing of end (bottom part).	and tape	20± 14. Chec of tape.	20 ± 3mm 3mm	20 ± 3mm	


			WORK INS	Effectivity Date:	March 7, 2025				
		Process Name/Title:	TAPIN	NG ASSEMBLY PRO	Validity Date:	n/a			
		Model code/Part number:	559D / 7N0237-7020B	Customer: TRJ	Car Model: TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-106	64B
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	5 of 6
PARTS:	1. Assy	parts				JIG:	n/a		
NO.	Р	ROCESS NAME	WORK	PROCEDURE/ ILLUST	TOOLS/PPE	QUALITY POINTERS			
5	P2	Measurement	NOTE: (A) - Taping (BR) (B) - Taping (B) (C) - Clamp (W) * Unit of dimension is in millimeter (mm)	② 20 ±2	WIR No. 1 2 3 4 5 White	White (6) 0 *5 E TYPE TABLE COIOT Wire Type B AVSS 0.3 f P AVSS 0.3 f W AVSS 0.3 f G AVSS 0.3 f SIEASURING TAPE	1. Please measuri measure 2. For Ha Docume 1. Refer sub-Ass	ent reference/s: to WI-PRO-ASY-csembly Hatsumon one and Owarimo	erified ing the varimono 056 For Io,

		WORK INSTRUCTION							Effectivity Date:	March 7, 2025		
		Process Name/Title:	TAPIN	TAPING ASSEMBLY PROCESS						n/a		
	Л	Model code/Part number:	559D / 7N0237-7020B		Customer:	TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-10	64B
	4	Purpose:	☐ PROTOTYPE		PRE-LAUNCH		MASSPE	RO	Revision No.:	0	Page No.:	6 of 6
PARTS:									JIG:			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING-P2

7N0237-7020B



- 1 No Wrong used of tapeY-taping
- ② No Missing SV tube (Vinyl)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.