


										tivity Date:		April 21, 2025		
			Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:			n/a		
	- 1		Model code/Part number:	412D / 628128-0000B	Customer: TRJ	Car Model:	TOYO	TA-RAV 4	Docu	ment No.:			WI-ENG-PDE-12	245
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSI	PRO		Revis	sion No.:		1	Page No.:	1 of 5
PARTS:		1. Assy	parts; Black tape						JIG:	n/a				
NO.		F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE QUALITY POINTERS			TERS		
1		P2	Table Lay-out	Assy parts	TABLE LAY-OUT	blder/ Black	ctape		f pi	Be sure to wear prescribed person rotective equipme during operation (gloves, finger cottect) Housekeeping Maintain and alway practice 5's. Personal things the workplace is trohibited. Keep it your locker. Alert level or any trouble, inforce Assembly Assist Supervisor or Line eader for immedia corrective action.	al ent s, s, ays on 1.1 in 2.1	No missi	ing parts/tools. ss parts/tools.	
Revision History										Prepared by	Check	ed by	Approved by	Noted by
										-				
04/21/25	1	Change document purpose from pre-launch to mass pro. A.Hernandez J.Loterte C. Villanueva A.Arañes								\bigcirc	الما	1/-/2-1/-	CHANGE	
04/16/25	0							C. Villanueva A.A	Arañes	Okum Con du / A.Hernandez	7.1	terte	C. Villanueva	A.Arañes
Eff. Date Rev. No Details of Change Revised Checked Reviewed Approved Est. Date: April 16, 2025														









Process Name/Title:	WORK INSTRUCTION TAPING ASSEMBLY PROC	Effectivity Date: Validity Date:	Apr	April 21, 2025 n/a							
Model code/Part number: 412D / 6281		Car Model: TOYOTA-	-	· '							
Purpose: PROTOTYPE	□ PRE-LAUNCH	☐ MASSPRO	Revision No.:	1 Page	No.: 5 of 5						
PARTS: 1. Assy parts			JIG:	n/a							
VISUAL INSPECTION/ QUALITY CHECKPOINTS											
P1 628128-0000B											
	Check the wire alignment. Make no tangled wires.		eck the terminal if with baded) or deformed terminal.	terminal if with backing out (not fully deformed terminal.							
BLACK VM TUBE (Sunprene)	BLACK VM TUE (Sunprene)	R VM TUBE (Sunp	orene)								
4. Check the orientation of harness.	5. Check if no missing p6. No Missing Tape	parts.(Retainer)	7. Compar tapping.	re to Master San	nple by						