				Effectivity Date:		January 21, 2025						
			Process Name/Title: CLAMP ASSEMBLY PROCESS					Validity Date:		n/a		
			Model code/Part number:	TM3 / 7L0115-7020 Customer: TRQSS Car Mo		Car Model: S	ar Model: SUBARU-ASCENT	Document No.:		WI-ENG-PDE-1071		
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	)	Revision No.:	0	Page No.:	1 of 5	
PARTS:	:	1. Assy į	parts; Gray Urethane foam t=	=4;75mmX30mm			JIG:	1. Assembly	1. Assembly jig			
NO.		Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(	QUALITY POINTERS			
1			Table lay-out		TABLE LAY-OUT			Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)				
	1	Clamp Assy		Assy parts	Housekeeping  1. Maintain and always practice 5's.  2. Personal things on the workplace is prohibited. Keep it in your locker.	Document references: 1. Refer to WI-ENG-PDE-315A-B for Taping Assembly process 1. No missing parts/tools 2. No excess parts/tools						
								Alert level For any trouble, inform the Assembly Assistar Supervisor or Line Leader for immediate corrective action.	nt			
		1		Revision History				Prepared by	Reviewed by	Approved by	Noted by	
01/21/25	/21/25 0 Initial issue. Separate from Taping assembly process.  D.Castillo C. Villanueva A. Arañes n/a C. Villanueva D.Castillo C. Villanueva A. Arañes							n/a				
Eff. Date	Rev. No			Details of Change		Revised Re	eviewed Approved N	/	nuary 21, 2025	, ,	.,,	
_												

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			WORK IN	ISTRUCTION		Effectivity Date:	January 21, 2025		
		Process Name/Title:	CLA	MP ASSEMBLY PROC	CESS	Validity Date:	n/a		
		Model code/Part number:	TM3 / 7L0115-7020	Customer: TRQSS	Car Model: SUBARU-ASCENT	Document No.:		WI-ENG-PDE-10	71
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 5
PARTS:		sy parts ay Urethane foam t=4; 75mm X 30mm				JIG: n/a			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS		
2	Clamp	Urethane foam attachment	Step 1: Identify the right facing to attached the foam  COT  Connector  Step 3: Atta	Step 2: Get the Urethane	e foam and begin the attachment. connector must be align  R  the connector.		1. No dama 2. No miss 3. No streto	OO NOT STRETCH URETHANE FO GOOD	Excess foam  The adm  Excess foam  The adm  The

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.


				Effectivity Date:		January 21, 2025				
		Process Name/Title: CLAMP ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	TM3 / 7L0115-7020	Customer: TF	RQSS Car Model: SUBAR	U-ASCENT	Document No.:		WI-ENG-PDE-10	71
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO		Revision No.:	0	Page No.:	3 of 5
PARTS:	1. Assy	parts				JIG:	1. Assembly jig			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(	QUALITY POIN	ΓERS	
3	Clamp Assy	Continuity test	CONNECTOR SETTING  1. Get the assy parts and set to tester correct setting). First set the connect checker fixture for continuity checking. Clip checker 1 then lock. Last, set the then press by toggle clamp.  2. Check in the counter if Wire 1 and Wire 2 was ON. If encountered abnormality, STOP and immediately CALL the attention of the leader. WAIT for further instruction then continue the process.	jig using both hands. or 6249-1252(W) to C . Second, set the conre e B-B wires to together	hecker 1 then pull the nector 7282-1020 (W) to	3. Press the SV index finger for sound will be h  4. Conduct PO removing the h  5. After point charness. Start f	W button using right continuity checking. Go	5. No wron 6. No expo	out tape off tape g use of tape g dimension-out ta	pe

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COP

**MASTER COPY** 




CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			Effectivity Date:		January 21, 2025				
		Process Name/Title:	CLAM	Validity Date:	n/a				
		Model code/Part number:	TM3 / 7L0115-7020	Customer: TRC	SS Car Model: SUBARU-ASCENT	Document No.:		WI-ENG-PDE-10	)71
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	1. Assy	parts	JIG:	n/a					
VISUAL INSPECTION/ QUALITY CHECKPOINTS									

**CLAMP ASSY** 

## 7L0115-7020



1 No Missing Tape (Blue Tape)

2 3 No Missing Tape (Black Tape)

4 No Missing Urethane Foam

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.