

Process Name/ Title:
PACKING INSTRUCTION

Product Code/Name:

7R0104

WORK INSTRUCTION

Customer Code:

TRMX

Document No: WI-QAD-QAC-188

Effective Date:

Rev. No.:

Page No.:

Page 1 of 1

July 2, 2024

Records/Remarks/ Work Procedure/ Illustration **Quality Pointers** 25pcs* Qty/box 100pcs. 4bdls. Mat'l Dim. Qty. name **TRMX** 544*370* Put Vinyl Sheet 1 1 box 228mm (1250 x 1250) inside TRMX box. Vinyl 1250*1250 1 sheet **Partition** 343*510 1 board **Plastic** 420*280 4 Vinyl bag 1. For CSW use Oricon box instead of TRMX box. Put 2 bdls. of products. 1. Step number 5 is applicable only in FG Inspection 2 (25pcs/bdl) in opposite direction. (3) Put partition board Put 2bdls. of products. 4 (25pcs/bdl) in opposite direction. No. of the last Fold the vinyl sheet. Put NBP Identification tag at the (5) top and tape the flaps (two side and top portion). Then Warehouse Identification tag at right side of the box. te: If need to attach 4M tag Put 4M tag at the left side Prepared Checked Noted Approved O. Merin 07/02/2024 Change vinyl sheet size from 1520 x 1500mm to 1250 x1250mm C. Dimailig M. Lumbres E. Mendoza madey Malabuyo J. Loterte A. Arañes

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY