

Layout the partition board vertically.



Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box.





Note: If need to attach 4M tag Put 4M tag at the left side of the box

						Prepared by	Reviewed by	Approved by
								1 /
02/03/24	1	Change document number from WI-ENG-PDE-608 to WI-QAD-QAC-234 and Remove Vinyl Sheet	M. Garcia	D.Dadulla	R.Pascua	Methodaile	Aua	ML
12/28/22	0	Initial Issuance	D. Castillo	J. Loterte	A. Arañes	M. Garqia	P.Dadula	.Pascue
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Establish Date:	December 28, 2022	,

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or nisappropriation, including unauthorized copying, reproduction in any orm, disclosure or publishing of this document or any information nerein is strictly prohibited.

**NBC (Philippines) MASTER COPY**