
PARTS: 1. Assy parts; Clamp 82711-52950 (W); Black tape [2pcs] NO. PROCESS NAME WORK PROCEDURE/ILLUSTRATION Table Lay-out Clamp 82711-52900 (W) Clamp Tray) Clamp Tray) Table lay-out Assy Parts Clamp 82711-52900 (W) Clamp Tray) Table lay-out Assy Parts Clamp 82711-52900 (W) Clamp Tray) Table lay-out Assy Parts Revision History Revision		_			WORK INSTRUCTION	Effectivity Date:		September 12, 2024				
PARTS: 1. Assy parts; Clamp 82711-52090 (W); Black tape [2pcs] NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION Table Lay-out Table Lay-out Clamp 8271-52090 (W) Clamp 3271-52090 (W) Clamp 3271-5				Process Name/Title:	CLAMP ASSEMBL	Y PROCESS		Validity Date:		n/a		
PARTS: 1. Assy parts; Champ 82711-52090 (W); Black tape [2]pcs] NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION Table Lay-out Safety Matruction Be suite to wear prescribed personal protective equipment during operation (glowes, injeer, one, etc.) 1. Assy Parts Clamp 82711-32090 (W) Clamp Tray Housekeeping 1. Maintan and always particle 5s, the workplace is prohibited. Keep it in your locker. Assy Parts Revision Healthy Table lay-out Assy Parts Revision Healthy Table lay-out Assy Parts Clamp 82711-32090 (W) Clamp Tray Housekeeping 1. Maintan and always particle 5s, the workplace is prohibited. Keep it in your locker. Complete States Alort level For any trouble, inform the Assembly Assistant Supervisor of Line Leader for immiddle. Corrective continue Leader for immiddle. Corrective				Model code/Part number:	890B / 7L0100-7021A Customer:	TRQSS Car Model:	TOYOTA-C-SUV	Document No.:		WI-ENG-PDE-1	041	
NO. PROCESS NAME WORK PROCEDURE/ILLUSTRATION TOOLS/PPE QUALITY POINTERS Table Lay-out Safety Instruction Be sure to wear prescribed personal clamp 82711-52090 (W) Clamp 17ay Housekeeping 1. Montain and always practice 5: 2. Personal things on the workplace is prohibited. Keep it in your locker. Assembly Assessmity jig Table lay-out Revision History Revision Fistory Revision Fistory Pageacetly Revision Fistory Pageacetly Revision Fistory Pageacetly Revision Fistory A Agroved by A				Purpose:	PROTOTYPE PRE-LAUNCH	MASSE	PRO	Revision No.:	1	Page No.:	1 of 5	
Table Lay-out Safety Instruction Be sure to wear prescribed personal protective equipment (gloves, inger cots, etc.) Clamp 82711-32090 (W) Clamp Trabe lay-out Assy Parts Clamp assymbly Process Personal things on the workplace is prohibited Keep in your locker. Clamp assymbly Process Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate cornocaive action. Revision History Revision History Revision History Presented by Revision By Assistant Council action of the Workplace is prohibited Keep in your locker. Clamp assembly process Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate cornocaive action. Revision History Revision History Revision History Revision Labarage. Presented by Revision By Approved by Revisional By Approved by Information Council action of the Workplace is prohibited from the Assembly Assistant Supervisor or Line Leader for immediate Council action in Management Council action (Chance By Approved by Information Council action (Chance By Approved by Information Council action (Chance By Approved by Information Chance By Approved By Approved By Approved By Approved By Approved By Approved	PARTS:		1. Assy	parts; Clamp 82711-52090 (V	W); Black tape [2pcs]	JIG:	1. Clamp as	1. Clamp assembly jig				
Clamp 82711-52090 (W) Clamp Table lay-out Assy Parts Clamp 82711-52090 (W) Clamp Tray Table lay-out Assy Parts Clamp 82711-52090 (W) Clamp Tray Table lay-out Assy Parts Clamp 82711-52090 (W) Clamp Tray Assy Parts Document reference/s: 1. Refer to Wi-ENC-PDE-405 for assembly process 2. No excess parts/tools 2.	NC).	F	PROCESS NAME	WORK PROCEDURE/	TOOLS/PPE	(QUALITY POIN	ITERS			
09/12/24 1 Change from Pre-launch to Masspro. A. C. Hernandez Villanueva A. Arañes n/a O9/10/24 0 Initial issue A. C. Hernandez Villanueva A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Hernandez Villanueva A. Arañes n/a A. Hernandez Villanueva A. Arañes n/a	1			Table lay-out	Assy Parts Clamp assembly	Clamp 82711-52 Clamp Tra		Be sure to wear prescribed personal protective equipmer during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things or the workplace is prohibited. Keep it ir your locker. Alert level For any trouble, infort the Assembly Assista Supervisor or Line Leader for immediate	Docume 1. Refer to assembly 1. No mission 2. No excess 6000	o WI-ENG-PDE-4 process Ing parts/tools ss parts/tools CLAMPILLUSTRATION		
1 Change from Pre-launch to Masspro. Hernandez Villanueva A. Arañes n/a O9/10/24 0 Initial issue A. C. Hernandez Villanueva A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Hernandez C. Villanueva A. Hernandez C. Villanueva A. Hernandez C. Villanueva					Revision History			Prepared by	Reviewed by	Approved by	Noted by	
09/10/24 1 Change from Pre-launch to Masspro. Hernandez Villanueva A. Arañes n/a A. C. Hernandez Villanueva A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Arañes n/a A. Hernandez A. H												
Hernandez Villanueva / A. Hernandez A. Hernandez A. Hernandez A. Hernandez			-			Hernandez	Villanueva A. Aranes	08 O (//- //-//-			
			Initial iss	ue		Hernandez	Villanueva A. Aranes	A. Hernandez()		A. Aranes	n/a	
Eff. Date Rev. No Details of Change Revised Revised Approved Noted Est. Date: September 10, 2024	Eff. Date	Rev. No]		Details of Change	Revised	Reviewed Approved	Noted Est. Date: S	September 10, 2024			

WORK INSTRUCTION Effectivity Date: September 12, 2024										
		Drassas Nama/Title			-					
		Process Name/Title:	CLAN	Validity Date: n/a						
		Model code/Part number:	890B / 7L0100-7021A	Customer:	TRQSS Car Model: T	OYOTA-C-SUV	Document No.:		WI-ENG-PDE-1	041
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	2 of 5
PARTS:	1. Clam 2. Black	p 82711-52090 (W) [2pcs] tape					JIG:	1. Clamp as	sembly jig	
NO.	PROCESS NAME		WORK	TOOLS/PPE	(QUALITY POIN	TERS			
2	Clamp	Clamp setting			2. Initially attach Black tape (1) and (2) using both hands	e on location	n/a	1. Pleas of asser parts. STA 1. No dama 2. No wron	e check the clampholy to avoid wrong the check the clampholy to avoid wrong the champ of the champ of the champholy to avoid wrong the champholy to avoid wrong the champholy the champh	o before start ng use of

	_		WORK INSTRUC	CTION	Effectivity Date:	September 12, 2024		
		Process Name/Title:	CLAMP AS	Validity Date:	n/a WI-ENG-PDE-1041			
	H	Model code/Part number:	890B / 7L0100-7021A C	UV Document No.:				
		Purpose:	PROTOTYPE PI	RE-LAUNCH MASSPRO	Revision No.:	1	Page No.:	3 of 5
PARTS:	1. Assy	parts			JIG:	1. Clamp as	ssembly jig	
NO.	F	PROCESS NAME	WORK PROC	EDURE/ ILLUSTRATION	TOOLS/PPE	(QUALITY POIN	TERS
3	Clamp	Clamp assembly	Receiver base 1. Last, set the terminal v	82711-52090 (W) SEQUENCE LIGHT Seabove picture for correct setting). First, set the convithin the stopper then press by Toggle clamp. Continu		Important reminders/Note/s: 1. Make sure no gap between terminal and stopper jig. 2. Make 2-3 windings for clamp taping 1. No wrong use of parts 2. No wrong use of tape 3. No damaged clamp 4. No wrong clamp position		
				and start taping(3 windings) using hatana		5. No wron	CLAMP ILLUSTRATION NG	32711-12A80 (W)



		WORK INSTRUCTION E							Effectivity Date:		September 12, 2024			
		Process Name/Title:	CLAMF	P ASSE	SEMBLY PROCESS			Validity Date:	idity Date: n/a					
		Model code/Part number:	890B / 7L0100-7021A	Custo	mer:	TRQSS	Car Model:	TOYOTA-C-SUV	Document No.:		WI-ENG-PDE-10	41		
		Purpose:	PROTOTYPE	PRE-L	AUNCH		MASSPI	RO	Revision No.:	1	Page No.:	5 of 5		
PARTS: 1. Assy parts							JIG:	n/a						

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7L0100-7021A



1 No Wrong Facing of Clamp

2 3 No Missing Tape (Black Tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.