		_	WORK INSTRUCTION							Effect	ivity Date:		June 11, 2024		
			Process Name/Title: TAPING ASSEMBLY PROCESS								ty Date:	•			
		H	Model code/Part number:	900B/910B	7N0070-7020C	Customer: TRJ	Car Model:	LEXU	JS-NX/RX	Docui	ment No.:		WI-ENG-PDE-4	160B	
			Purpose:	PROTOTYP	E	PRE-LAUNCH	MASSE	PRO		Revis	ion No.:	6	Page No.:	1 of 4	
PARTS:		1. Assy լ	parts; Black tape								JIG:	n/a	n/a		
NO.		Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION							TOOLS/PPE		QUALITY POINTERS		
1	1	P2	Table Lay-out		S. J. P. C. ST. P. S. J. C. P. S.			Assy parts	1	1. 2. wo	Be sure to wear or or corective equipme ring operation (glor finger cots, etc.)  Housekeeping Maintain and alway practice 5's. Personal things on or kplace is prohibit eep it in your locks.  Alert level or any trouble, infor e Assembly Assistation or Line Lear immediate correct action.	ays the 1. No mis 2. no excer.	sing parts/tools.		
					Revision History		1		1		Prepared by	Reviewed by	Approved by	Noted by	
6/11/24	6	(Vinyl) to tube (Vi	ed process of Taping Blac o wire near connector 60 nyl) to wire near connector d tape to connector from-	98-3810 then transfer or 6098-3802 from P3	red to P3; Transferred p	process of Taping Blac	k SV	C. Villanueva	A. Arañes	n/a					
8/15/23	5	Change from 2MP to 3MP. Transferred process of Y-taping 1 and 2 to P3; Transfered process no.1, 15,16 and 17 from P1 to P2 due to change process distribution; Transfered process of Clamp setting; Clamp Assembly; Visual/By two's inspection and measurement from P2 to CLAMP ASSEMBLY PROCESS. Standardized tube description: SV tube (Vinyl); VM tube (Sunprene); Change table lay-out.  M. Ariola  J. Loterte C. Villanue								A. Arañes	M. Acida	South Thouse	A. Aranes	n/a	
Eff. Date	Rev. No	Details of Change					Revised	Reviewed	Approved	Noted	Est. Date:	April 12, 2022			

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			WORK INS	Effectivity Date:	June 11, 2024				
		Process Name/Title:		G ASSEMBLY PROC	Validity Date:	-			
		Model code/Part number:	900B/910B 7N0070-7020C		Customer: TRJ Car Model: LEXUS-NX/RX		WI-ENG-PDE-460B		
		Purpose:	□ PROTOTYPE	PRE-LAUNCH	MASSPRO	Document No.:  Revision No.:	6	Page No.:	2 of 4
		т агросс.				The tribile in the in		. ago . to	2 0
PARTS:	1. Assy 2. Blac			JIG: n/a					
NO.	1	PROCESS NAME	WORK P	TOOLS/PPE	QUALITY POINTERS				
2	P2	Taping 1 Black COT to wire near terminal	Start of taping  1. Hold the COT using left hand, get the Black tape using right hand then start pre-taping using both hands.  131 ± 3mm	2. Confirm measurement of then continue the taping produced by the state of the sta	3mm  23 4 5 6  R  25±3mm from end of tape up to COT cess using both hands.  Sure from end of COT up to terminal tip 131±3mm then continue the process using both hands.	6 7 8 9 40 1 2 3 4 5 6 7 8 9	1. Pleas measuris measure  1. No flip-ou 2. No peel-c 3. No Loose 4. No Missir 5. No wrong	it tape off tape tape ng tape	rified

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			WORK INSTRI	Effectivity Date:	June 11, 2024				
		Process Name/Title:		ASSEMBLY PROC	Validity Date:	-			
		Model code/Part number:	900B/910B 7N0070-7020C	Car Model: LEXUS-NX/RX	Document No.:	WI-ENG-PDE-460B			
		Purpose:		Customer: TRJ	MASSPRO	Revision No.:	6	Page No.:	3 of 4
		. a.pooc.							
PARTS:	1. Assy 2. Black		<b>A</b>		JIG:	n/a			
NO.	I	PROCESS NAME	6 WORK PRO	TOOLS/PPE	QUALITY POINTERS				
3	P2	Taping 2 Black SV tube (Vinyl) to wire near connector	1. Measure from end of SV tube (Vinyl) up to end of connector 25±3mm using both hands.	2. Hold the assy pusing right hand a (Vinyl) and wires. (Note: Do not folwires)  3. After taping taping conditions.	Start of taping  Parts using left hand. Get Black tape and start pre-taping between SV tube and start pre-taping between SV tube and the SV tube (Vinyl) ø5 with 3  In the SV tube (Vinyl) ø5 with 3  In the SV tube tape width 25±3mm.	n/a	1. No flip-o 2. No peel- 3. No loose 4. No miss 5. No wron 6. No wron  Note: ( -From ( broken	ut tape off tape e tape	ce to avoid

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

		WORK INSTRUCTION E							Effectivity Date:	June 11, 2024		
		Process Name/Title:	ne/Title: TAPING ASSEMBLY PROCESS							-		
		Model code/Part number:	900B/910B	7N0070-7020C	Customer:	TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-4	60B
		Purpose:	PROTOTYPI	E [	PRE-LAUNCH		MASSPR	0	Revision No.:	6	Page No.:	4 of 4
PARTS:	n/a								JIG:	n/a		
										<u> </u>		
VISUAL INSPECTION / QUALITY CHECKPOINTS												

**P2** 

## 7N0070-7020C



1 2 No Missing Tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.