

Process Name/ Title:
PACKING INSTRUCTION

Document No:

Effective Date:

WI-QAD-QAC-254

October 16, 2024

WORK INSTRUCTION
Product Code/Name: Custor

A7469

Customer Code: TRQSS

Rev. No.:

1

Page No.:

Page 1 of 1

		A7469	IRQSS					
No.		Work Procedure/ Illustration				Records/Remarks/ Quality Pointers		
1)	(12	ut Vinyl Sheet 1250 x 1250) ide carton box.				Qty/box Mat'l	75	25pcs*3bdls
					name DC carton	Dim.(mm)	Qty.	
					Vinyl sheet	1250*1250	1	
						Vinyl bag	420*280	3
2		Put first bdl of oducts. (25pcs.)			Plastic vinyl bag of CSW assy	Note : Step num Inspection.	ber 4 is applicable	e only in QC FG
3	Put 2nd with	and 3rd bdl on upper oposite direction.	2nd bundle	3	Brd bundle			
4	Fold the	vinyl sheet and close the flaps.		Note : If need to Put 4M to	o attach 4M tag			
						Prepare	Check	Approve
10/16/2024	1	Change vinyl s	heet size from 1520x1500 to 1250x1250	S. Malabuyoc	D. Dadulla R. Pascua/ O. Merin	Cmaldeym	Qua	MH VE
04/24/2024 Eff./Rev. Date	0 Rev. No.		Initial Issue Details of change	A. De Chavez Revise	D. Dadulla R. Pascua Check Approve	S) Malabuyoc Est. date:	D. Dadulla April 24, 2	R. Pascva/ O Merin
					1	1		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY