
					WORK I	NSTRUCTION				Effectivity Date:		September 8, 20	23
			Process Name/Title:		OFF	LINE ASSEMBLY P	ROCESS			Validity Date:		n/a	
			Model code/Part number:	700B	/ 7N0039-702	OA Customer: TRJ	Car Model:	TOYOTA-LAND	D CRUISER	Document No.:		WI-ENG-PDE-73	31
	<u></u>		Purpose:	PROT	OTYPE	PRE-LAUNCH	MASS	PRO		Revision No.:	0	Page No.:	1 of 6
PARTS:	,	1. Con	nector 6098-3802 (W); AVS	SSf 0.3 B-V wire	L=763±3mm					JIG:	1. Insertion 2. Locking	ı jig with switch cov jig	er
NO.		PROCESS NAME WORK PROCEDURE/ ILLUSTRATION							TOOLS/PPE	G	QUALITY POINT	ERS	
1		n/a	Table lay-out	Inse	ertion Jig with flip cover	TABLE LAY-OU'	r I	Black SV tube (Vinyl) 5 L=193±3mm		Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the work place is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. No missi 2. No excess Doc 1. Refer to Wire and	ing parts/tools ss parts/tools cument reference/ to WI-PRO-CNC-0 I Strip Length Tole	's: 17 for
-					Revision Histor	ТУ		T		Prepared by F	Reviewed by	Approved by	Noted by
09/8/23	0	Initial iss Excluded	ue. Il process from WI-ENG-PDE-71			ew process distribution.	M. Ariola				J. Loterte	c. Villanueva	A. Araijes
Eff. Date Re	v. No			Detail	ls of Change		Revised	Reviewed App	proved No	ted Est. Date: Septe	ember 8, 2023		

MASTER COPY



	_			WORK INSTR	Effectivity Date:	September 8, 2023					
		Process Name/Title: OFFLINE ASSEMBLY PROCESS					Validity Date:	n/a			
		Model code/Part number:	700B /	7N0039-7020A	Customer: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	'31	
		Purpose:	PROTOTYF	E [PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 6	
PARTS:	1. AVS	Sf 0.3 B-V wire L=763±3mm						1. Insertion	Insertion jig with switch cover		
NO.	I	PROCESS NAME		WORK PR	OCEDURE/ ILLUS	TRATION	TOOLS/PPE	QUALITY POINTERS			
3	n/a	Wire insertion to insertion jig 6098-3802 (W)	1. Get the Black to terminal slot 1 hand. 3. Get the Violet w terminal slot 2 us	vire then insert to	4. Aft	After insertion of Black wire press the utton using right hand. The slot for olet wire will be opened. R R R R R R R L Press er insertion, press the lock using left of and then hold the wires and gently pulling the connector from jig using right hand.		Important 1. Please 2. Make s inserted. Conduct insertion Do not e. Documer 1. Refer t Push pro 2. Refer t	g insertion one insertion med terminal g wire facing of reminders/Note hold the wire ne sure wires are pl Pull-Push-Pull-F . xert extra force. of CL-PRO-ASY-(ear terminal. Push after 229 for Pull-	

			WORK INSTRU	Effectivity Date:	September 8, 2023					
		Process Name/Title:	OFFLINE A	Validity Date:	n/a					
		Model code/Part number:	700B / 7N0039-7020A	Customer: TRJ Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	31		
		Purpose:	□ PROTOTYPE □	PRE-LAUNCH MASSPRO F	Revision No.:	0	Page No.:	4 of 6		
PARTS: 1. Assy					JIG:			1. Locking jig		
NO.	F	PROCESS NAME	WORK PRO	TOOLS/PPE	QUALITY POINTERS					
4	n/a	Connector lock	1. Load the connector into the jig holding both side of the connector, tip first. Right thumb-Lower Left thumb-middle 3. Press the lower parts of connector using right hand while left hand holding the middle. Right thumb-middle Left thumb-middle 5. Lift then press the connector in the middle using left and right hand.	Right thumb-upper Left thumb-middle 4. Press the upper part of connector using right		Important 1. Manuadamaged 1. Use the connector.	nt reminders/Note al locking may ca d connector lock provided jig tool to	NG Half Lock e/s: puse		

WORK INSTRUCTION Effectivity Date: September 8, 2023										
		Process Name/Title: OFFLINE ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	700B /	7N0039-7020A	Customer: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	'31
		Purpose:	PROTOTYF	E	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	5 of 6
PARTS:	1. Assy 2. Black	parts < SV tube (Vinyl) ø5 L=193	JIG:	n/a						
NO.	Р	ROCESS NAME		WORK P	ROCEDURE/ ILLUS	TRATION	TOOLS/PPE	QUALITY POINTERS		
5	n/a	Wire insertion to Black SV tube (Vinyl) ø5 L=193±3mm	Get Black SV tu	be (Vinyl) ø5 L=193±3r then insert Black and vand.	R mm Wiolet		n/a	1. No wron 2. No defo	g use of parts rmed terminal	

	Effectivity Date:	September 8, 2023				
Process Name/Title:		VORK INSTRUCTION OFFLINE ASSEMBLY PRO	DCESS	Validity Date:	n/a	
Model code/Part number:	TM3 / 7N003	39-7020A Customer: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:	WI-ENG-PDE	731
Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0 Page No.:	6 of 6
PARTS: n/a				JIG:	n/a	
		QUALITY CHI	ECKPOINTS			
OFFLINE INS	ERTION	7	N0039-702	0A		
	ock connectoring insert		rminal Backing O	ut	GOO NO GO	DOD