

Document No: Effective Date: WI-QAD-QAC-203

October 28, 2024

Customer Code:

			7L0124	TRQS		Rev. No.:	2	Page No	).: <b>[</b>	Page	1 of 1
No.	Work Procedure/ Illustration							Records/Remarks/ Quality Pointers			
		Put Vinyl	A	M	1			Qty/box	64	2	32pcs *2bdls
		(1250 x 1250)		10	1			Mat'l name	Dim		Qty.
	insi	de carton box.						DC carton	1131*7	781	1
1					W.			Vinyl sheet	1250*1	250	1
								Vinyl bag	420*2	80	2
2	Put first bundle of products. (32pcs/bundle)							Note: Step number 5 is applicable only in <b>QC FG Inspection</b> .			
3	other s	ond bundle on the side with opposite direction 2pcs/bundle) 2									
4	Fold	the vinyl sheet.									
(5)	Close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box).  Note: If need to attach 4M tag Put 4M tag at the left side						ag				
							Prepare	Ch	eck	Ap	pprove
10/28/2024	2		ity per bundle from 25pcs to 32 pcs cking quantity from 50 pcs to 64 pcs	A. De Chavez	D.Dadulla	R.Pascua/					
6/4/2024	1	Change document control n Change Vinyl Sheet Size fr	o. from WI-ENG-PDE-382 to WI-QAD-QAC-238. om 1520x1500 to 1250x1250; Change picture of b. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	O. Merin  R.Pascua				Ju, /	Rei
8/27/2022	0		Initial issuance	M. Garcia	R. Alcantara	A. Arañes	X. De Chave			R.Pascu	ıa/ O. Merin
Eff./Rev. Date	Rev. no.		Details of change	Prepared	Checked	Approved	Established. d	ate:			-

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information nerein is strictly prohibited.

**NBC** (Philippines) **MASTER COPY**