

Process Name/ Title:

PACKING INSTRUCTION WORK INSTRUCTION

Document No:

Effective Date:

WI-QAD-QAC-049

June 4, 2024

Product Code/Name:

7L0049

Customer Code: **TRQSS**

Rev. No.:

3

Page No.: Page 1 of 1

	7 L0043 TNQ33								
No.		Work Procedure/ Illustration					Records/Remarks/ Quality Pointers		
1	<u>/</u> 3\	Put Vinyl Sheet (1250 x 1250) nside carton box.	<u></u>		<u>^3</u>	Qty/box Mat'I name DC carton Vinyl sheet	50 pcs. Dim. 1131*781 1250*1250	25pcs* 2bdls Qty. 1	
2	Put fir	Plastic vinyl bag of Contact SW assy Put first bundle of products. (25pcs.)					Plastic vinyl bag Note: 3 Step number Inspection.	420*280 5 is applicable only	2 n QC FG
3	Put seco	and bundle on upper with pposite direction. (25pcs.)							
<u>3</u> 4	Fold the vinyl sheet .								
(5)	Close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box .		Note: If need to attach 4M tag Put 4M tag at the left side						
		Change Vinyl Sheet Size from	1520y1500 to 1250y1250: Change picture of po. 1:				Prepare	Check	Approve
06/04/2024	3	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.		J. De La Cruz	D.Dadulla	R.Pascua			, ,
08/24/2022	2	use Oricon Dox Instead of DC Dox			R. Alcantara	A.Arañes	8/_	(A. /	M. /
07/08/2021 10/01/2018	0		moval of Silica gel and Bubble Sheet	C.Dimailig C.Dimailig	M.Lumbres M.Lumbres	E Mendoza	J. Do Cruz	D.Dadulla	R.Pascua
Eff./Rev. Date	Rev. No.		Details of change	Revise	Check	Approve	Est. date:	10/01/20	18

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. **NBC** (Philippines) **MASTER COPY**