Process Name/ Title:
PACKING INSTRUCTION

WI-QAD-QAC-269

WORK INSTRUCTION

Effective Date:
June 27, 2024

Product Code/Name:
Customer Code/ Customer:
Rev. No.: 1

Page No.: Page 1 of 1

			/R0131		IRMX				-		
No.	Work Procedure/ Illustration						Records/Remarks/ Quality Pointers				
1				la de					Qty/bo x	400	50pcs*8 bdls
	Put Vinyl Sheet (1250 x 1250) inside TRMX box.						1		Mat'l name	Dim.	Qty.
									TRMX box	544*370* 228mm	1
			3/1	27	3/2			1	Vinyl sheet	1250* 1250	1
2			5	Opcs × 4bdls		P	lastic vinyl ba CSW assy	g of	Partition board	343* 510	1
	th	products inside the box					Vinyl bag	420* 280	8		
	bu	direction per indle) 4 bundles)						Note : Step 5 is applicable only in QC FG inspection.			
3				1st	LAYER				For CSW proinstead of T		Oricon box
	Layout partition board										
4	insid (opposite b	other bundles le the box e direction per undle) * 4 bundles)	2ND LAYER								
(5)	Put NBP tag at the the flaps top Then I	e vinyl sheet. Identification top and tape (two side and portion). Warehouse cation tag at de of the box.		Note: If need to attach 4M tag Put 4M tag at the left side of the box							
							F	repared by	Checked by	Approved by	Noted by
06/27/24 06/2/22	1 0	Initial Issue	1250 x 1250. Transferred from WI-ENG-PDE-539	S. Malabuyoc K. Doria	R. Pascua J. Loterte	O. Merin C. Villanueva		maldeyu Malabuyoc	R Haseua	9 Merin	···· <del>-</del> ···
Eff. Date	Rev. No.	De	etails of change	Prepared	Checked	Approved	Noted Es	tablish Date:	June	2/2022	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY