

	Process Name/ Title:						
	PACKING INSTRUC	Documer	nt No:	WI-QAD-QAC-209			
٦.	WORK INSTRUCTION	Effective Date:		June 19, 2024			
	Product Code/Name:	Customer Code:					
	71 0116	TROSS	Rev. No.:	1	Page No.:	Page 1 of 1	

		·	7L0116	TRQSS	Rev. No.: 1	Page N	lo.: Page	1 of 1
No.	Work Procedure/ Illustration				Records/Remarks/ Quality Pointers			
						Qty/ box	70	35pcs *2bdls
				CO &		Mat'l name	Dim.	Qty.
1	Put Vinyl Sheet (1250 x 1250) inside carton box.					DC carton	1131*781	1
						Vinyl sheet	1250*1250	1
						Vinyl bag	420*280	2
2	Put first bund products. (35pcs/				Plastic vinyl bag of CSW assy	Note : Zigname Step nu in QC FG	umber 5 is appli Inspection.	cable only
3	Put second bun the other side opposite direc (35pcs/bund	with ction dle)						
4	Fold the vinyl s	sheet.						
(5)	Close the flaps a NBP Identificatio the top of the pla Warehouse Ident tag at the right sid front of the b	on tag at estic and tification de of the			d to attach 4M tag M tag at the left side			

						Prepare	Check	Approve /
						,		1 /
06/19/2024	1	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua	-	Ma	M
08/27/2022	0	Initial issuance	M. Garcia	R.Alcantara	A. Arañes	J. De (a)cuz	D.Dadulta	R.Pascua
Eff./Rev. Date	Rev. no.	Details of change	Prepare	Check	Approve	Established date:	August 27, 2022	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) **MASTER COPY**