| NA | | | | | | | | | | | Effec | tivity Date: | | January 22, 2025 | | | |
|-----------|--|--------------|---|-------------------------|--|------------------|-----------------------|---------------|--------------------------------|------------------|-----------|--|--|--|--------------|----------|--|
| | | | Process Name/Title: | TAPING ASSEMBLY PROCESS | | | | | | | Valid | ity Date: | | n/a | | | |
| | | | Model code/Part number: | 311D | 1 | 7L0154-7023 | Customer: | TRQSS | Car Model: | TOYO | TA-RAV4 | Docu | ment No.: | | WI-ENG-PDE-1 | 026B | |
| | | | Purpose: | ☐ PF | ROTOTYPE | | PRE-LAUNCH | 1 | MASS | PRO | | Revis | sion No.: | 2 | Page No.: | 1 of 5 | |
| | | 1 | | | | | | | | | | - | | 1 | <u> </u> | | |
| PARTS: | | 1. Assy į | parts; Black VM tube (Sunpr | ene) ø9, L=97 | ±3mm ; Bla | ack tape | | | | | | | JIG: | n/a | | | |
| N | NO. PROCESS NAME WORK PROCEDURE/ ILLUSTR | | | | | | | | ATION | | | | TOOLS/PPE | | QUALITY POIN | ITERS | |
| | | | | | TABLE LAY-OUT Black VM tube (Sunprene) ø9, L=97±3mm | | | | | | 99, | pı | afety Instructi Be sure to wear orescribed person otective equipm during operation gloves, finger cot etc.) | al ent | | | |
| 1 | 1 | P2 | Table lay-out | Table lay-out | | | | | | | 1. 2. | Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. | | No missing part/tools. No excess parts/tools | | | |
| | | | | | | Assy parts | Γape holder/l tape | Black | 3 | | | the Le | Alert level or any trouble, info e Assembly Assist Supervisor or Line eader for immedia corrective action | tant e ate | | | |
| | | L | | <u> </u> | | Revision History | | | | | | | Prepared by | Reviewed by | Approved by | Noted by | |
| 01/22/25 | 2 | | I Quality pointers "No insufficie | ent tape" and ad | dd document | | countermeasur | e to customer | D. Castillo | C. | A. Arañes | n/a | i repared by | i teviewed by | Approved by | Noted by | |
| | | claim. | | | | | | | | Villanueva C. | | | | | | | |
| 10/02/24 | 1 | | ourpose from Pre-launch to Ma | sspro. | | | | | M. Ariola Villanueva A. Arañes | | n/a | Estuo | South House | South form | | | |
| 09/10/24 | 0 | Initial issu | е. | | | | | | M. Ariola | C. Villanueva | A. Arañes | n/a | D. Castillo C. Villanueva A. Arañes | | | n/a | |
| Eff. Date | Rev. No | | Details of Change Revised Reviewed Approv | | | | | | | | Approved | Voted | Est. Date: | September 10, 202 | 4 | | |



| | | | WORK INSTRUCT | ION | Effectivity Date: | T | January 22, 20 | 25 | | |
|--------|---------------------|---|---|---|--|--|--|--------------------------------|--|--|
| | | Process Name/Title: | TAPING ASS | EMBLY PROCESS | Validity Date: | | n/a | | | |
| | | Model code/Part number: | 311D / 7L0154-7023 Cus | tomer: TRQSS Car Model: TOYOTA-F | AV4 Document No.: | | WI-ENG-PDE-10 | 26B | | |
| | | Purpose: | PROTOTYPE PRE | -LAUNCH MASSPRO | Revision No.: | 2 | Page No.: | 2 of 5 | | |
| PARTS: | 1. Assy 2. Black | | | | JIG: | n/a | | | | |
| NO. | I | PROCESS NAME | WORK PROCE | DURE/ ILLUSTRATION | TOOLS/PPE | (| QUALITY POINTERS | | | |
| 2 | P2 | Taping 2 Black Corrugated tube to Wire near PCB | Start of taping 1. Get the Black tape using right hand then start taping process using both hand. 25 ± 3mm R 3. Confirm measurement from end of tape up to end of COT 25±3mm then continue the taping process using both hands. | 2. Measure from end of COT up to Hotmelted L=108±3mm then continue the taping process using both hands. 4. Confirm measurement from end of CO end of tape 25±3mm then continue the tap process using both hands. | MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 2 2 3 4 5 6 7 8 9 10 2 3 2 3 4 5 6 7 8 9 10 2 3 2 3 2 2 3 2 2 3 2 2 2 2 2 2 2 2 2 | Importa 1. Please measure Docum 1. Reference Taping 1. No flip-or 2. No peel- 3. No loos 4. No wror 5. No wror 6. No miss | ant reminders/le use calibrated/ving tape when getement. ment references r to WI-PRO-ASY-process out tape -off tape ie tape in g dimension ing use of tape | Note/s: erified ting the | | |



| | | | WORK INSTRUCTION | | Effectivity Date: | | January 22, 202 | 25 |
|--------|----|---|--|--|---|---|---|-----------------------------|
| | | Process Name/Title: | | | Validity Date: | | n/a | |
| | | Model code/Part number: | 311D / 7L0154-7023 Customer: | TRQSS Car Model: TOYOTA-RAV4 | Document No.: | | WI-ENG-PDE-10 | 26B |
| | | Purpose: | ☐ PROTOTYPE ☐ PRE-LAUNCH | Maidity PROCESS Validity Date: N/a Maidity Date: N/a M | | | | |
| PARTS: | | VM tube (Sunprene) ø9, L=9 | | | | | | |
| NO. | F | ROCESS NAME | WORK PROCEDURE/ | ILLUSTRATION | TOOLS/PPE | (| QUALITY POIN | TERS |
| 3 | | Wire insertion to Black VM tube (Sunprene) ø9, L=97±3mm | L=9 | 7±3mm using right hand then insert the | n/a | 1. No wrong | g use of parts. | |
| 4 | P2 | Taping 3 Black Corrugated tube to VM tube (Sunprene) | | 2. Hold the VM tube (Sunprene) using left hand, get the Black tape then start taping using right hand. R 3. After taping, check the | MEASURING TAPE 6 7 8 9 (1) 1 2 3 4 5 6 7 8 9 (| 1. Pleas measur measur 1. Refer Taping 1. No flip-c 2.No peel-3. No loose 4. No wror 5. No wror 6. No miss | ne use calibrated/ving tape when genement. nent references r to WI-PRO-ASY- process but tape off tape e tape ig dimension ig use of tape ing tape | verified tting the S: |



| | _ | | | WORK INST | RUCTION | | | Effectivity Date: | $\overline{}$ | January 22, 202 | 5 |
|--------|-----|-------------------------|---|-------------|-----------------|---------|-------------|---|---|------------------|--------------------------------------|
| | | Process Name/Title: | | | ASSEMBLY PR | OCESS | | Validity Date: | + | n/a | |
| | | Model code/Part number: | 311D / | 7L0154-7023 | | | TOYOTA-RAV4 | Document No.: | <u> </u> | WI-ENG-PDE-102 | 26B |
| | | Purpose: | □ PROTOTYPE | | PRE-LAUNCH | MASSP | | Revision No.: | 2 | Page No.: | 4 of 5 |
| PARTS: | n/a | | | | | | | JIG: | n/a | | |
| NO. | F | PROCESS NAME | | WORK PR | ROCEDURE/ ILLUS | TRATION | | TOOLS/PPE | 1 | QUALITY POIN | TERS |
| 5 | P2 | Measurement | NOTE: (a) - Taping (B) (b) - dimension of overlapped Sunp | Ø 25±5 | ③25±5 E | ® 25 | No. (| TYPE TABLE Color Wire Type G AVSS 0.3 f BW AVSS 0.3 f MEASURING TAPE | Import 1. Pleas measurimeasurin 2. For H Owarim Docum 1. Pleas Sub-Ass | latsumono, Nakan | erified ing the nono and ASY-056 for |



| NBA | Process Name/Title: | Effectivity Date: Validity Date: | January 22, 2025 n/a | | | | | | | | |
|------------|-------------------------|----------------------------------|-------------------------|--------------------|--------|------------|-------------|------------------------------|-----|---------------|--------|
| MBG | Model code/Part number: | 311D / □ PROTOTYPE | 7L0154-7023 | Customer: T | RQSS | Car Model: | TOYOTA-RAV4 | Document No.: Revision No.: | 2 | WI-ENG-PDE-10 | 5 of 5 |
| | Purpose: | ☐ PROTOTIPE | |] PRE-LAUNCH | | MASSPR | | Revision No | | Page No.: | 5015 |
| PARTS: n/a | | | | | | | | JIG: | n/a | | |
| | | | VISU | AL INSPECTIO | N/QUAL | ITY CHEC | KPOINTS | | | | |
| TA | PING - P | 2 | | | Ž. | 71 | 0154-7 | 023 | | | |
| Gunn | | | | | | | | | | | |
| | | | | | | | | 3 | 1 | | |
| 1 N | o MISSIN | IG VM to | ube (Sui | npren | e) (| 2 | 3 1 | lo MISS | ING | TAPI | E |

NBC (Philippines)
MASTER COPY