									June 18, 2024		
			Process Name/Title: CLAMP ASSEMBLY PROCESS						Effectivity Date: June 18, 2024 Validity Date: n/a		
	-1		Model code/Part number:	660B / 7R0111-7021	Customer: TRMX	Car Model: TOY	OTA-SEQUOIA	Document No.:		WI-ENG-PDE-7	96
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	1 of 5
			parts: Clamp 82711-12A60	(W)			JIG:		1. Clamp assembly jig		
NO	Ο.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POINTERS		
1		Clamp Assy	Table Lay-out	Assy parts	Table Lay-out Clamp 82711-12A60 (W)	Cla Black tape/ Tape holder	amp Assembly jig	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistar Supervisor or Line Leader for immediate corrective action.	Docume 1. Refer to 7R0111-7 PROCESS 1. No miss 2. No exce	ing parts/tools ss parts/tools	SEMBLY
Т				Revision History		1		Prepared by	Reviewed by	Approved by	Noted by
									,/ / • "	CALLE	
06/18/24	0	Initial issu	e.			D.Castillo C.Villano	ueva A. Arañes	n/a D. Castillo	C. Villanueva	A. Arañes	n/a
Eff. Date	Rev. No			Details of Change		Revised Review	ved Approved N		ine 18, 2024	, , , ,	.,,
•				-		•	*				_




	WORK INSTRUCTION Effectivity Date: June 18, 2024									
		Draces Name/Title		Effectivity Date: Validity Date:	June 18, 2024					
		Process Name/Title:		ASSEMBLY PROC				n/a		
	7	Model code/Part number:	660B / 7R0111-7021	Customer: TRMX		Document No.:		WI-ENG-PDE-7	96	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6	
PARTS:	1. Assy 2. Clarr	parts p 82711-12A60 (W)				JIG:	Clamp assembly jig			
NO.	F	ROCESS NAME	WORK PI	ROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	QUALITY POINTERS			
2	Clamp Assy	Clamp Setting	1. Get set to		SO (W) using right hand then		1. Please start of a clamp. 1. No wron 2. No dam. 3. No wron	ant reminders/le check the Clamp ssembly to avoid very sembly sem	first before vrong use of	



			Effectivity Date:	June 18, 2024						
		Process Name/Title: CLAMP ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	660B / 7R0111-7021	Customer: TRMX	Car Model: TOYOTA-S	SEQUOIA	Document No.:		WI-ENG-PDE-7	796
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	4	Page No.:	3 of 6
PARTS:	1. Assy parts					JIG:	1. Clamp assembly jig			
NO.	P	ROCESS NAME	ROCESS NAME WORK PROCEDURE/ ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS				
3	Clamp Assy	Clamp assembly	CONNECTOR SETTING 1. Get the assy parts and set into jig. (connector 6098-3802 (W) to Checker to set the harness in jig. Set the V-V w Color sensor light will beep/buzz if se stopper jig then press by toggle clamp 2. Initially tighten the band clamp on clusing both hand. 3. Get the bando gun using right hand clamp on location 1. Press the SW bu sound will be heard. 4. Conduct POINT CHECKING before harness from jig.	(See above illustration for concentration of the pull the checker fixturing together within the stopensor detects Yellow tape. So. Continue if the sequence library lamp location 1	GOOD NG BANDO GUN ALIGNMENT ERPENDICULARITY OK NG OK N	Continue e clamp. within the	BANDO GUN	1. Make stand termin 1. No loos 2. No dam 3. No miss 4. No miss 5. No gap EXTENDED Import 1. Using measure dimension	ant reminders/Nure no gap between als e clamp attached age clamp and tape aing parts between terminal and and another terminal another terminal and another terminal another terminal and another terminal another te	and stopper TION NG NOSEPIECE O ~ 2mm Note/s: At if the band cut required thould not








			Effectivity Date:	June 18, 2024					
		Process Name/Title:	CLAM	Validity Date:	n/a				
		Model code/Part number:	660B / 7R0111-7021	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-7	796
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 6
PARTS:	1. Assy	y parts				JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

CLAMP ASSY

7R0111-7021



- - 3 No Missing Band Clamp
- **7** No Deformed Terminal

- **2** No Wrong Insert
- 4 5 6 No Missing Tape
- 8 Checking of loose/tight band clamp attachment

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY