


									Effectivity Date:		April 16, 2025		
			Process Name/Title:  Model code/Part number:	CLAMP ASSEMBLY PROCESS  400D / 7L0167-7020D				Validity Date: n/a Document No.: WI-ENG-PDE-12		244			
		<u> </u>	Purpose:	400D / 7L0167-7020D Customer: TRQSS Car Model: TOYOTA bZ4x (BEV		A 024X (BEV)	Revision No.:	0	Page No.:	1 of 7			
PARTS:		1. Clamp 82711-34490 (B) 2. Clamp 82711-52090 (W) [3pcs]		3. Clamp 82712-12080 (B) 4. Black tape [4pcs]					JIG:	1. Tempora	Temporary Clamp assembly jig		
NO	NO. F		ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(	QUALITY POINTERS		
1	1	Clamp	np Clamp setting	82711-52090 (W) 82711-34490 (B)	82712-12080 (B) 82711-52090 (W)				Safety Instructi  Be sure to wear prescribed person protective equipm during operation (gloves, finger cot etc.)	alal 1. Referent Taping 1. S.,	Document reference/s:  1. Refer to WI-ENG-PDE-1198 for Taping assembly process  1. No damaged clamp		
				5 4 1 3					Housekeepine  1. Maintain and alw practice 5's.  2. Personal things the workplace is prohibited. Keep it your locker.	3. No missi 4. No wrong ays on 6. in	2. No wrong use of clamp 3. No missing clamp 4. No wrong orientation of clamp  CLAMP ILLUSTRATION  GOOD  NG  82711-52090 (W)  82711-12A80 (W)		
				Get 1pc. of clamp 82712-12080 (B) using right hand and set to clamp location 1 using both hands.      Get 1pc. of clamp 82711-34490 (B) using right	4. Get 2pcs. of clamp 82711-52090 (W) using right hand and set to clamp location 4 and 5 using both hands.				Alert level For any trouble, info		BAND CLAMP ILLUSTRATION GOOD NG 82711-34490 (B) 82711-16830 (B)		
				hand and set to clamp location 2 using both hands.	5. Initially attach Black tape to clamp location 1, 3, 4 and 5 using both hands.				the Assembly Assis Supervisor or Lin Leader for immedia	ate			
				3. Get 1 pc. of clamp 82711-52090 (W) using right hand and set to clamp location 3 using both hands.					corrective action	1000			
Revision History Prepared by Checked by									Reviewed by	Approved by			
04/16/25		Initial iss	ue.			A.Hernandez	J.Loterte	C.Villanueva A	Arañes A.Hernandez	J.Loterte	Long Hours	A. Arañes	
Eff. Date Rev. No Details of Change Revised Checked Reviewed Approved Est. Date: March 26, 2025													


NBC (Philippines)


MASTER COPY












	<u> </u>	WORK INSTRUCTION				Effectivity Date:	April 16, 2025			
		Process Name/Title:	CLAMP ASSEMBLY PROCESS			Validity Date:	n/a			
		Model code/Part number:	400D / 7L0167-7020D	Customer: TRQSS	Car Model: <b>FOYOTA bZ4x (BEV</b>	Document No.:		WI-ENG-PDE-12	244	
		Purpose:	□ PROTOTYPE ■	PRE-LAUNCH	☐ MASSPRO	Revision No.:	0	Page No.:	7 of 7	
									7	
PARTS:	n/a	v/a					n/a			
VISUAL INSPECTION/ QUALITY CHECKPOINTS										

## **CLAMP ASSY**

## 7L0167-7020D



- 1 Check the Clamp Alignment
- 2 No Missing Tape
- 3 No Wrong Facing of QR code

- 4 No Missing Clamp
- 5 No Wrong Facing of Y-Taping
- 6 No Missing Clip Clamp Attachment to Clamp 82712-12080