

Process Name/ Title: Document No: WI-QAD-QAC-053 **PACKING INSTRUCTION** Effective Date: June 4, 2024

WORK INSTRUCTION Product Code/Name:

7L0050

Customer Code: **TROSS**

Rev. No.:

3

Page No.:

Page 1 of 1

		7L0050 TRQSS							Tage No.: Tage 1011			
No.		Work Procedure/ Illustration							Records/Remarks/ Quality Pointers			
	<u>/3</u> \ (Put Vinyl Sheet (1250 x 1250)							Qty/box	144 pcs.	72pcs* 2bdls	
	ins	side carton box.							Mat'l name	Dim.	Qty.	
1				$\stackrel{\frown}{\searrow}$		TA			DC carton	1131*781	1	
						MAR		$\sqrt{\frac{3}{3}}$	Vinyl sheet	1250*1250	1	
					-30				Plastic vinyl bag	420*280	2	
2	Put firs	t bundle of prod (72pcs.)	ducts.					e vinyl bag of act SW assy	Note: 3 Step number 5 Inspection.	is applicable only ir	QC FG	
3	Put second bundle with opposite direction. (72pcs.)											
<u>3</u> 4	Fold the vinyl sheet.											
(5)	Close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box .			Note: If need to attach 4M tag Put 4M tag at the left side								
									Prepare	Check	Approve	
06/04/2024	3	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.				J. De La Cruz	D.Dadulla	R.Pascua			, /	
08/24/2022	2	Remove "Note: For CSW process disregard step 4 a use Oricon box instead of DC box"			1 and	M. Garcia	R. Alcantara	A.Arañes	-8/	. /	Me/	
07/08/2021 10/01/2018	1 0			update location of tags in step nu Removal of Silica gel and Bubble sheet		C.Dimailig C.Dimailig	M.Lumbres M.Lumbres	E Mendoza E Mendoza	J. De Druz	D.Dadulla	R.Pascua	
Eff./Rev. Date	Rev. No.			Details of change		Revise	Check	Approve	Est. date:	10/01/20	118	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) **MASTER COPY**